

Philips
Micro Hi-Fi System



MC145

Great Sound and Compact Design

Great sound in a compact, elegant design! The classic MC145 delivers dynamic sound performance and the essential functionalities that will let you enjoy music just the way you like it.

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Autostop cassette deck
- Dynamic Bass Boost for deep and dramatic sound
- 4W RMS total output power

Wake up to CD or radio tunes

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience

Fits any space, any lifestyle

- Compact design

PHILIPS

Specifications

Sound

- Output Power: 2x2W RMS / 2x4W music power
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

Loudspeakers

- Main Speaker: 3" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program
- Loader Type: Top
- Cassette Deck Technology: Mechanical

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20

Connectivity

- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, MW Antenna

Convenience

- Alarms: Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

Accessories

- Included accessories: FM/MW Antenna
- Remote control: 19-key with battery

Dimensions

- Set dimensions (W x H x D): 168 x 224 x 214 mm
- Main speaker dimensions (W x H x D): 130 x 224 x 213 mm
- Packaging dimensions (W x H x D): 496 x 308 x 284 mm
- Weight incl. Packaging: 5.7 kg

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2014-02-06

Version: 1.0.5

12 NC: 9073 100 13459
EAN: 87 10895 97797 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com