



Philips
Portable Radio

Classic design
DAB

AE5900



Enjoy clear and crackle-free digital radio

Comes with an elegant leather finish, the Philips digital radio also has line-in connectivity for your MP3 player. Its built-in alarm clock and cooking timer makes it an ideal bedroom or kitchen companion.

Enjoy digital quality DAB radio

- Interference-free DAB radio
- DAB and FM compatible for a complete radio experience
- Line-in connection for your portable music playback

Excellent sound reproduction

- Bass Reflex Speaker System delivers a powerful, deeper bass
- 4W RMS total output power

Easy to use

- Built-in digital alarm clock with cooking timer
- 10 DAB and 10 FM preset stations
- Elegant leather finishing

PHILIPS

Specifications

Tuner/Reception/Transmission

- DAB: info display, smart scan, menu
- Tuner bands: FM, DAB (Band III)
- Station presets: 20
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning

Sound

- Volume control: rotary (digital)
- Output power: 4 W RMS

Loudspeakers

- No. of built-in speakers: 1
- Speaker drivers: 3" full range woofer
- Loudspeaker enhancement: bass reflex speaker system

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Display type: LCD display

- Alarms: repeat alarm (snooze)
- Backlight color: white
- Clock: sleep timer

Power

- DC input voltage: 9 V
- Power type: AC Input

Accessories

- Cables/Connection: AC-DC adapter
- Others: User Manual
- Warranty: Warranty Certificate

Dimensions

- Gross weight: 2.6 kg
- Packaging depth: 165 mm
- Packaging height: 169 mm
- Packaging width: 310 mm
- Weight: 2.4 kg
- Main unit depth: 130 mm
- Main unit height: 124 mm
- Main unit width: 269 mm

Highlights

Interference-free DAB radio

DAB (Digital Audio Broadcasting) digital radio is, on top of FM analog transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in crystal clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can be found. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no returning on the move.

Bass Reflex Speaker System

Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Built-in alarm clock with cook

Built-in digital alarm clock with cooking timer

10 DAB and FM preset stations

10 DAB and 10 FM preset stations



Issue date 2014-02-07

Version: 2.0.3

12 NC: 8670 000 31635
EAN: 87 12581 34684 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com