

Philips
Noise Canceling
Headphone



SHN5200



75% Less External Noise

Active Noise Canceling

Blockout irritating background noise and enjoy your music in peace - with these headband style headphones that actively cancel background noise by up to 75%. Ideal for use in airplanes and trains

Optimal listening in noisy environments

- Compact electronics eliminate unwanted external noise by 75%
- Soft ear cushions provide a perfect seal for perfect sound

Made to fit you and your lifestyle

- Easy adjustable headband ensures optimum fit and comfort
- Slim lightweight controls for power

Always ready to go

- Adapter for in-flight entertainment system connection
- Battery included so you can use your product straight away

PHILIPS
sense and simplicity

Specifications

Sound

- Acoustic system: Open
- Diaphragm: Mylar dome
- Impedance: On: 245 ohms; Off: 132 ohms
- Magnet type: Neodymium
- Maximum power input: 30 mW
- Sensitivity: 104 dB
- Speaker diameter: 34 mm
- Type: Dynamic
- Voice coil: Copper
- Active noise attenuation: 10 dB at 100 Hz; 50-1000 Hz
- Frequency Range: 18-20000 Hz

Connectivity

- Cable length: 1.4 m
- Connector: 3.5 mm stereo
- Finishing of connector: Gold plated
- Type of cable: OFC

Accessories

- Airplane plug: Yes, 2 * 3.5 mm

- Battery: Yes, 1.5V Battery LR03/AAA
- Protective pouch: protective pouch included

Packaging dimensions

- Packaging dimensions (W x H x D): 19.6 x 20.3 x 4.5 cm
- Nett weight: 0.13327 kg
- Gross weight: 0.32127 kg
- Tare weight: 0.188 kg
- UPC: 6 09585 19637 7
- Number of products included: 1
- Packaging type: Blister

Outer Carton

- Outer carton (L x W x H): 22.2 x 16.7 x 27 cm
- Nett weight: 0.39981 kg
- Gross weight: 1.15708 kg
- Tare weight: 0.75727 kg
- GTIN: 1 06 09585 19637 4
- Number of consumer packagings: 3

Highlights

75% Noise Canceling

Smart noise canceling technology enhances the pleasure of listening to lower volume levels in noisy environments. It's particularly good at removing low-frequencies like jet engine noise, so you can enjoy soft music on flights, and in trains and similar places without hearing a distracting buzz in the background. The technology actually creates an equal but opposite waveform to the unwanted noise that effectively cancels it out.

Airplane adaptor included

Use your own headphones to listen to in-flight entertainment. The adaptor simply converts the standard double-mono jacks to a stereo headphone jack.

Battery included

No need to buy batteries to get started. Just drop the batteries in and go!

Easy adjustable headband

The easily adjustable mechanism provides a comfortable close fitting acoustic seal between the ear cushion and ear, ensuring optimal performance.

Soft sealing ear cushions

The ear cushions are very soft, and enclose the speakers around the ears to create a perfect seal & great sound. With very little pressure on the ears, you can use the headphones comfortably for long periods.



Issue date 2013-01-31

Version: 10.1.5

12 NC: 8670 000 67905
UPC: 6 09585 19637 7

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com