

Philips



MX3910D



Bring your movies and music to life

Turn your living room into a digital home theater. You will enjoy deep and powerful bass with wide and warm multichannel surround sound, bringing your movies and music to life.

Unrivalled audio and video performance

- Class 'D' Digital Amplifier for quality sound performance
- DTS 5.1 Dolby Digital Pro Logic II full surround sound
- Progressive Scan component video for optimized image quality
- Cinema Center Speaker™ for realism cinematic experience

Plays practically any disc format

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, CD-R/RW and MP3-CD
- Picture CD (JPEG) with music (MP3) playback

PHILIPS

sense and simplicity

Specifications

Product highlights

Class D Amplifier

Class 'D' Digital Amplifier takes an analog signal, converts it into a digital signal and then amplifies the signal digitally. The signal then enters a demodulation filter to give the final output. The amplified digital output delivers all the advantages of digital audio, including improved sound quality. In addition, Class 'D' Digital Amplifier has greater than 90% efficiency compared to traditional AB amplifiers. This high efficiency translates into a powerful amplifier with a small footprint.

DTS, Dolby Digital 5.1 and PL2

A Built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Cinema Center Speaker™

Recreate and experience realism cinematic experience right in your environment with Cinema Center Speaker™. With a wider sweet spot delivered by four multi-directional woofers and a high frequency tweeter positioned precisely at different angles, more sound depths are distinguished from front and background and action from dialogue. Natural and crystal clear sound reproduction are created through the revolutionary new 2" full range woofers to give an incredible 'through the screen' experience which creates the sensation of being not just in the cinema but in the movie itself.

Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

Multi-format Music

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

Picture CD with MP3 Playback

Picture CD is a CD-R or CD-RW disc on which you can store your MP3 and digital pictures. When inserting a Picture CD in the DVD player, a screen menu will pop up, showing your JPEG's and/or MP3 files on the disc. Just select the music and pictures files you wish to enjoy and press play or OK. You can watch your pictures on TV with your music playing simultaneously.



Date of issue 2007-01-15

Version: 1.0

12 NC: 9073 100 12218

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com