

PHILIPS

Wireless HiFi Headphone

FM transmission

Comfort fit

Up to 14 hours play time

SHC5200



Wireless freedom

Fully rechargeable wireless headphones

No more hassles with the cables, you can feel free to move around at home for music enjoyment. With the rechargeable and lightweight design of these Philips SHC5200/10 headphones, you don't need to bother for long wearing time.

Comfortable for long use

- Self-adjusting inner headband
- Lightweight design improves comfort for prolonged use.

The perfect wireless listening experience

- 32mm speaker driver delivers high performance sound
- FM Wireless transmission for freedom of movement

Convenience

- Fully rechargeable
- Choose from 2 channels to minimize interference

Specifications

Sound

Frequency range: 10 - 20,000 Hz

Speaker diameter: 32 mm

Impedance: 24 Ohm

Maximum power input: 50 mW

Sensitivity: 96 dB (1K Hz)

Signal/noise ratio: 65 dB

Distortion (THD): < 2%

Driver type: Dynamic

Connectivity

Wireless

Maximum range: Up to 100 m

Type of wireless transmission: FM

Headphone socket: 3.5 mm

Outer Carton

Length: 32.5 cm

Number of consumer packagings: 3

Width: 26 cm

Gross weight: 2.87 kg

Height: 32.5 cm

GTIN: 1 69 23410 73294 5

Nett weight: 1.26 kg

Tare weight: 1.61 kg

Convenience

Automatic power off

Power

Rechargeable

Number of batteries: 2 x AAA 1.5V

Music play time: 14 hour(s)

Battery type(Headphones): NiMH rechargeable batteries

Packaging dimensions

Height: 32 cm

Packaging type: Box

Type of shelf placement: Hanging

Width: 24 cm

Depth: 10 cm

Number of products included: 1

EAN: 69 23410 73294 8

Gross weight: 0.754 kg

Nett weight: 0.42 kg

Tare weight: 0.334 kg

Product dimensions

Height: 22 cm

Width: 19.5 cm

Depth: 8.5 cm

Weight: 0.178 kg

Accessories

Others: Antenna tube, 2 x AAA NiMH batteries

Docking station (transmitter)

Included adapters: AC/DC adapter

Design

Color: Black

Wearing style: Headband

Ear coupling material: Fabric

Ear fitting: Over-ear

Earcup type: Closed-back

Highlights

32 mm speaker driver

The 32 mm speaker driver is a compact yet powerful element for delivering non-distorted sound with any given input power.

Self-adjusting inner headband

Typically headphones worn outdoors are adjustable by sliding an extendable headband into position. This can be cumbersome as it usually has to be done every time you use it. Get your music fix faster and easier with these headphones' flexible, self-adjusting inner headband. It will automatically adjust to your head's shape and size.

Lightweight design

The durable, lightweight quality materials of these Philips headphones enhance comfort for extended wearing.

FM Wireless transmission

With high frequency FM wireless transmission, which can even pass through walls, you can even listen to your music when you're in another room.

Fully rechargeable

The headphones are designed to be used with rechargeable batteries. No worry on cost for repeated use.

2 transmission channels

With a choice of two transmission channels your listening pleasure is protected because you can easily switch to the one with the best reception.

