

Philips
Mini Hi-Fi System

MP3-CD playback
USB Direct

FWM185



Listen to favorite MP3-CD music in rich sound

with USB Direct playback

Experience uninterrupted enjoyment of your CD/MP3/WMA songs for up to 10 hours on the FWM185. Extend your music pleasure by listening to your tunes at home from your portable player - with USB Direct and MP3 player-in.

Enrich your sound experience

- 2-Way Bass Reflex Speaker System for powerful sound
- 120W RMS total output power

Continuous enjoyment of your favorite music

- 10 hours of MP3-CD music
- AM/ FM tuner for radio enjoyment
- Stereo cassette deck
- USB Direct for MP3/WMA music playback
- MP3 player-in for your portable music device

Personalized sound settings

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings

PHILIPS

Specifications

Sound

- Output power (RMS): 4x30W/ch
- Output Power: 2000W PMPO
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- Main Speaker: 4" woofer, 2" tweeter, 2 way, Bass Reflex Speaker System
- Number of Loudspeakers: 2

Audio Playback

- Number of Discs: 1
- Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- USB Direct Modes: Fast Backward/Fast Forward, Play/Pause, Previous/Next, Program Play, Repeat, Stop
- Disc Playback Modes: Repeat/one/disk/program, Shuffle Play, Fast Forward/Backward, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start

Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

Convenience

- Alarms: CD Alarm, USB alarm, Sleep timer
- Clock: On main display
- Display Type: LCD

Connectivity

- Aux in: 3.5mm stereo
- USB: USB host

Accessories

- Included accessories: Remote Control, Guarantee booklet, Quick Use Guide
- User Manual: English, Spanish, B-Portuguese

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 272 mm
- Packaging dimensions (W x H x D): 525 x 413 x 410 mm
- Weight incl. Packaging: 10.450 kg

Power

- Power supply: 100-240VAC, 50/60Hz

Highlights

2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

AM/ FM tuner

AM/ FM tuner for radio enjoyment

Stereo cassette deck

Stereo cassette deck

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

120W RMS

This system has 120W RMS total output power. RMS refers to Root Mean Square which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.



Issue date 2014-02-05

Version: 10.0.12

12 NC: 8670 000 29039
EAN: 87 12581 32976 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com