



Philips  
DVD player

Karaoke

DVP3026K



# Turn up your experience

With 6 channel out

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

## Great audio and video performance

- Progressive Scan component video for optimized image quality
- 192kHz/24 bit audio DAC enhances analogue sound input

## Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio
- Photos: Picture CD (JPEG)

## Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

## Your personal karaoke show

- Karaoke for endless singing entertainment

# PHILIPS

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original

analogue sound wave form, giving a much richer audio reproduction.

## Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

## Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

## Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and

play most disc formats for maximum disc compatibility and viewing pleasure.

## Ultra-slim design

The attractive enclosure has a very low profile.

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



# Specifications

## Picture/Display

- Aspect ratio: 16:9, 4:3
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 80 dB
- Crosstalk (1kHz): 90 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital, DTS, Dolby Prologic II

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW
- Compression formats: MPEG1, MPEG2
- Video disc playback system: PAL, NTSC

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW
- Compression format: PCM, MP3, Dolby Digital, DTS, WMA
- MP3 bit rates: 32 - 256 kbps

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom

## Connectivity

- Front / Side connections: Microphone
- Rear Connections: Composite video (CVBS) output, Digital coaxial out, ComponentVideo out
- Progressive, Analog audio Multi-channel out

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Simplified Chinese, Traditional Chinese, Malay, Thai, Korean
- Karaoke: MIC volume

## Power

- Power supply: 50/60 Hz, 110-240V
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W

## Accessories

- Included accessories: Audio/Video cable, Quick start guide, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual, Power cord

## Dimensions

- Set dimensions (W x H x D): 360 x 37 x 235 mm
- Packaging dimensions (W x H x D): 415 x 82 x 320 mm



Issue date 2014-02-10

Version: 4.0.7

12 NC: 8622 810 13345  
EAN: 87 10895 94111 2

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)