



#### Internet Radio

- DAB+
- Spotify connect
- Bluetooth®

TAPR802/98

## More to love

Whatever you're into, get into it more with this Philips internet radio. As well as internet, DAB, and FM tuning, you also get Spotify Connect compatibility and the ability to stream from your mobile device.

### Benefits

#### Find what you want

- Internet radio. Thousands of stations at your fingertips
- Spotify Connect. Use a mobile device as a Spotify remote
- Bluetooth wireless music streaming
- DAB+/FM digital radio
- Digital tuning with up to 20 presets

#### Hear what you love

- 1x 3" full-range driver. Clear, detailed sound

### Features

#### Thousands of stations

Music. Spoken word. True crime. This internet radio is your ticket to thousands of global stations broadcasting every conceivable kind of program. The digital radio tuner delivers crystal-clear reception and you can set up to 20 presets for your favorite internet, DAB+, or FM stations.

- Bass-reflex port. Full, powerful low tones

#### Day and night

- Big 2.4" color display for easy viewing
- Built-in clock function with dual alarms and Sleep Timer
- DC-in. Mains-powered

#### Sleek looks. Clear screen.

The matte black wooden cabinet surrounds a large, high-gloss color display, and a black metal speaker grille. The display shows album art and song information from Spotify Connect, and station logos when you use internet radio or DAB.

# PHILIPS

### Crisp sound and punchy bass

A 3" full-range speaker delivers clear sound. A bass-reflex port fills in the low tones, giving you rounded, powerful bass response. The wireless range is 10 m.

### Easy streaming. Epic listening

Streaming from Spotify? This Bluetooth internet radio boasts Spotify Connect. Use your mobile as a remote control while the radio streams Spotify's best-

quality signal—directly from the Spotify servers. You can also stream from other music services via your mobile device.

### Alarm clock and sleep timer

The Sleep Timer lets you drift into restful sleep with your favorite radio station playing in the background. The Dual Alarm function lets you set two different alarms. Perfect if you're likely to snooze through the first alarm. Or if your partner needs to wake before you.

## Specifications

[field not found 'disclaimer\_text']

### Tuner/Reception/Transmission

Auto digital tuning	Yes
Tuner bands	FM Internet Radio DAB/DAB+
DAB	info display menu smart scan
Station presets	20 FM, 20 DAB, 20 Internet radio/ Podcast, 10 Spotify
RDS	Yes.

Snooze (repeat alarm)	DAB radio Internet radio No
-----------------------	-----------------------------------

### Display

Type	2.4" TFT color display
------	------------------------

### Power

Mains power	AC 5V, 2A
Power supply	100-240VAC, 50/60Hz

### Accessories

Included accessories	AC-DC Adapter Quick start guide Warranty certificate
----------------------	--

### Product dimensions

Depth	10.2 cm
Height	10.6 cm
Weight	0.74 kg
Width	18.5 cm

### Packaging dimensions

Depth	13.4 cm
EAN	48 95229 10229 3
Gross weight	0.98 kg
Height	15.1 cm
Nett weight	0.78 kg
Tare weight	0.2 kg
Number of products included	1
Packaging type	Box
Type of shelf placement	Laying
Width	27.2 cm

### Connectivity

Bluetooth	Yes
Bluetooth profiles	A2DP AVRCP
Bluetooth range	10M (free space)
Bluetooth version	4.2
Audio in	No

### Sound

Output power (RMS)	3W
Sound System	Mono
Volume control	rotary (digital)

### Loudspeakers

Number of full range drivers	1
Full range driver diameter	3"

### Convenience

Clock update	DAB / Internet radio
--------------	----------------------

### Alarm

No. of alarms	2
Alarm source	Buzzer FM radio



data subject to change  
2023, June 19

Version: 6.1.2  
EAN: 4895229102293

© 2023 Koninklijke Philips N.V.  
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

[www.philips.com](http://www.philips.com)