

Philips
CD Soundmachine



AZ2537

Connect to Great Games and Excitement

With Max Sound

Uniquely designed with dual orientation, you can set it vertically or horizontally to fit and enhance any space. Cool beyond imagination, you'll also get a blast out of Philips' Gameport and Max Sound for the ultimate gaming and music exper

Powerful sound you can hear and feel

- MAX Sound for instant power boost
- Bass Reflex speakers deliver a powerful, deeper bass

Ready for gaming

- Gameport enables a truly realistic gaming experience
- Sound mode presets to maximize your gaming pleasure

Feature-packed CD player

- MP3-CD, CD-R/RW compatible

Unique design for any space

- Vertical Positioning for aesthetic, space-saving players

PHILIPS
sense and simplicity

Highlights

MAX Sound



MAX Sound technology produces an instant boost in bass, maximizing volume performance and instantly creating the most impressive listening experience with just the touch of a button. Its sophisticated electronic circuitry calibrates existing sound and volume settings, instantly boosting bass and volume to maximum levels without distortion. The end result is a noticeable amplifying of both sound spectrum and volume and a potent audio boost that will add mileage to any music.

Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the

low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.

Gameport

Gameport is an easy connection solution that links your game console directly to your audio system for enhanced gaming sound quality. Game Sound Mode offers 3 exciting sound settings - Speed mode gets the adrenaline going in high-speed driving and flying games while Punch mode adds power to the punch in hand-to-hand combat games. Finally Blast mode lets you experience the full explosive effects of battle games. A Game Mix function, MIX-IT, available on Mini Hi-Fi Systems, allows game sounds to be mixed with a favorite CD track, radio station or external audio player.

Sound mode presets

Sound mode presets to maximize your gaming pleasure

MP3-CD, CD-R/RW compatible

MP3-CD, CD-R/RW compatible

Vertical Positioning

Vertical Positioning saves space and enhances the aesthetics of your set by giving you the choice of positioning your CD Soundmachine in either the conventional horizontal position or in the attractive, space-saving vertical position. Innovative technology and design ensure that the system works just as well in a vertical orientation as in a horizontal one. In addition, a specially designed CD Soundmachine stand holds the set firmly in place so you can enjoy high quality performance in a vertical position.



Specifications

Sound

- Equalizer: 3-bands
- Equalizer settings: Gamesound (Blast,Punch,Speed)
- Loudspeaker types: Bass Reflex Speaker System
- Output power (RMS): 2X4W
- Sound Enhancement: MAX Sound, Treble and Bass Control
- Sound System: Stereo
- Speaker diameter: 4"
- Volume Control: Volume Control rotary/encoder

Loudspeakers

- Built-in speakers: 2
- Finishing: Metal
- Loudspeaker Enhancement: Max BASS Port
- Loudspeaker types: Loudspeakers

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Album Search, Next/Previous Track Search, Repeat one/album/all, Shuffle Play
- Loader Type: Top
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Tuner Bands: AM, FM

Connectivity

- Audio input for data: Audio Left/Right (RCA) 2x
- Aux in: Gameport
- Headphone: 3.5 mm
- Video input: CVBS Video (RCA) 1x
- Video Output - Analog: Composite CVBS (yellow cinch)

Convenience

- Backlight
- Backlight color: Amber
- Display Digits: 7
- Display Type: LCD

Accessories

- Included Accessories: AC Power Cord, Audio/Video cable, User Manual, Warranty certificate
- Stand: Stand for vertical position

Dimensions

- Packaging dimensions (W x H x D): 645 x 230 x 348 mm
- Product dimensions (W x H x D): 520 x 178 x 287 mm
- Weight: 4.5 kg
- Weight incl. Packaging: 6.5 kg

Power

- Battery type: LR20
- Battery voltage: 1.5 V
- Mains power
- Number of batteries: 8



Issue date 2009-05-22

Version: 3.0.4

12 NC: 9073 101 01317

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com