

Philips  
Portable DVD Player



PET715



## Enjoy Your Favorite DVD Movies On The Go

Sit back, relax and immerse in movies on the go with the ultra cool and compact PET715 with 17.8 cm (7") TFT LCD display. Enjoy multi-media ease with MPEG4 and DivXR digital media format.

### Immerse in AV entertainment on the go

- Play, DVD, DVD+R and DVD+RW
- DivX playback for high compression video
- MPEG4 playback ensures high-quality compressed video
- Plays CD-RW and MP3-CD
- Photos: Picture CD (JPEG)

### Comfortable viewing anywhere

- 17.8 cm (7") TFT color LCD screen
- Watch movies in 16:9 widescreen format

### The ultimate in convenience

- Car adaptor and handy remote control included
- Up to 2.5-hour playback with rechargeable battery
- Dual headphone jacks for the share of entertainment fun
- Travel case included

# PHILIPS

# Highlights

## DivX playback

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, memory cards and DVD-video. DivX CDs can be played back on selected DVD

players, DVD Recorders and Home Theater Systems.

## MPEG4 playback

MPEG4 is a compression standard allows you to record movies at up to seven to 10 times smaller than the MPEG2 standard without compromising on the picture and sound quality. MPEG4 media can be saved on a CD-

Rom, memory card or DVD disc and can be played back in selective DVD players, DVD recorder and Home theater systems.

## Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.



# Specifications

## Picture/Display

- Brightness: 400 cd/m<sup>2</sup>
- Contrast ratio (typical): 250:1
- Diagonal screen size (inch): 7 inch
- Display screen type: LCD TFT
- Effective viewing area: 154.1x86.6mm
- LCD panel type: Anti-glare polarizer
- Pixel pitch: 0.107(w)x0.370(H)mm
- Resolution: 480(w)x234(H)x3(RGB)
- Response time (typical): 30 ms

## Sound

- Output Power: 250mW RMS(built-in speakers)
- Output power (RMS): 10mW RMS(earphone)
- Signal to noise ratio: >80dB(earphone), >62dB(built-in speakers)

## Video Playback

- Compression formats: MPEG4, DivX 3.11, DivX 4.x, DivX 5.x
- Playback Media: DVD, DVD+RW, DVD+R, Picture CD, SVCD, Video CD
- Disc Playback Modes: A-B Repeat, Angle, Disc Menu, Fast Backward, Fast Forward, OSD, Repeat, Shuffle Play, Slow Backward, Slow Forward, Zoom
- Video disc playback system: NTSC, PAL

## Audio Playback

- Compression format: Dolby Digital, MP3
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- File systems supported: ISO-9660, Joliet
- MP3 bit rates: 32 - 320 kbps

## Connectivity

- Audio Output - Analog: Audio L/R (cinch)
- Audio Output - Digital: Coaxial (cinch)
- AV input: Composite (CVBS) x1
- AV output: Composite (CVBS) x1
- Connector: 2 x 3.5 mm Headphones
- DC in: 9V
- Power: 30W

## Convenience

- Battery charging indication
- Shock proof

## Accessories

- AC/DC Adaptor: ADPV18A(110-240v, 50/60Hz)
- Battery pack: DV 7.4V, Li-ion rechargeable batteries
- Cables: Audio Cable x1, Video Cable x1
- Car kit: cigarette outlet adaptor, 12vDC
- Included accessories: Travel pouch
- Remote control: RC810(credit card style, 38 keys)
- User Manual: English/ French/ German/Spanish

## Dimensions

- Master carton dimensions: 540 x 264 x 375 mm
- Master carton quantity: 3
- Packaging dimensions (W x H x D): 360 x 249 x 188 mm
- Packaging type: D-box
- Product dimensions (W x H x D): 190 x 30 x 155 mm
- Product weight: 0.9 kg



Issue date 2017-04-04

Version: 1.0.2

12 NC: 9073 101 02142  
EAN: 87 10895 90885 6

© 2017 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)

\* Rechargeable batteries have a limited number of charge cycles and may eventually need to be replaced. Battery life and number of charge cycles vary by use and settings.