

Philips
Micro Hi-Fi System

- MP3/WMA-CD playback
- USB Direct

MCM119



USB Direct Playback

Specifically designed for one who appreciates the ultimate in technology and style, the system exudes finesse and quality. With USB Direct, you can play and remote control your MP3/WMA files from your portable player and USB storage devices.

Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB devices
- Play MP3/WMA-CD, CD and CD-RW

Enrich your sound experience

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2 x 20 W RMS/2 x 40 W music power/800 W PMPO

Start the day your way

- Wake-up and sleep timer functions
- Digital tuning with 40 pre-set stations for extra convenience

Refined in sound and look

- Elegant wood-finished speakers

PHILIPS

Highlights

USB Direct for MP3/WMA music

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses

graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of

the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2 x 40 W Music Power
- Output power (RMS): 2 x 20 W
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost

Loudspeakers

- Main Speaker: 4" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Repeat/one/all/programme, Shuffle Play, 40-Track Programmable
- USB Direct Modes: Play/Pause, Previous/Next, Programme Play, Repeat, Shuffle, Stop
- ID3-tag support
- Loader Type: Top

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Aux in: Line in
- Other connections: FM Antenna, MW Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Eco Power Standby: 1 watt
- Display Type: VFD display

Accessories

- Included accessories: FM/MW Antenna
- Remote control: 22-key remote with Lithium battery
- Cables: 1500 mm D-sub cable
- USB cable: 250 mm USB Cable

Dimensions

- Set dimensions (W x H x D):
218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D):
125 x 250 x 270 mm
- Packaging dimensions (W x H x D):
322 x 314 x 450 mm
- Weight incl. Packaging: 8.5 kg



Issue date 2013-05-10

Version: 1.0.4

12 NC: 8670 000 32738
EAN: 87 12581 35457 2

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com