



Philips
Micro Hi-Fi System

MP3/WMA-CD playback

wall-mountable

MCM240B

Unique wall-mountable design

Trendy and progressive, unique innovation and style appeals to you. And so will the vividly chic MCM240B with dynamic sound performance packed in a sleek design with MP3-CD playback that can also be wall mounted.

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 400W PMPO / 10W RMS total power

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

Design that blends into your interior

- Front motorized CD door with viewing window
- Wall-mountable option for flexible placement

PHILIPS
sense and simplicity

Specifications

Sound

- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Output Power: 400W PMPO
- Output power (RMS): 2x5W

Loudspeakers

- Main Speaker: Bass Reflex Speaker System, 3" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 40-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Front, Motorised
- ID3-tag support

Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store
- Station presets: 40

Connectivity

- Headphone: 3.5 mm
- Other connections: FM Antenna, MW Antenna
- Audio Connections: Analogue Audio In (L/R)

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue
- Wall mountable / Ceiling Throw: Wall Mountable

Accessories

- Included accessories: FM/MW Antenna, Screws for wall mounting x2, AC Power Cord, World Wide Warranty leaflet
- User Manual: English, Traditional Chinese
- Quick start guide: Eng, Trad. Chin
- Remote control: 23-key with battery

Dimensions

- Set dimensions (W x H x D): 250 x 245 x 96 mm
- Main speaker dimensions (W x H x D): 166 x 245 x 90 mm
- Packaging dimensions (W x H x D): 328 x 313 x 300 mm
- Weight incl. Packaging: 5.4 kg

Power

- Power supply: 110-240V, 50/60 Hz

Highlights

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2011-01-09

Version: 1.0.2

12 NC: 8670 000 38586
EAN: 87 12581 40899 2

© 2011 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com