

Philips CD Soundmachine with Dynamic Bass Boost

MP3

AZ1302

Play MP3 music and digital tuning

You take pleasure in the simple things in life and delight in convenience. The sleek and portable AZ1302 lets you indulge in the pleasures of enjoying your favorite MP3 music with the help of easy-to-use functions.

Your complete MP3-CD experience

- 10 hours of MP3-CD music
- Compatible with CD-Recordable and CD-ReWritable
- Digital tuning with preset stations for extra convenience
- Autostop cassette deck

Bass sound experience

• Dynamic Bass Boost for deep and dramatic sound

Easy to use and precise control

- Autostore Programming for one-touch radio tuning
- Multi-functional LCD display
- · Stereo headphone socket
- · Handy remote control



Specifications

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Programmable Tracks: 20
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle
- · Number of decks: 1
- · Cassette Deck Technology: Mechanical

Audio Recording

- Tape Recording Enhancement: CD Synchro Start
- Recording Media: Tape

Tuner/Reception/Transmission

- Tuner Bands: FM, MW
- Station presets: 20
- · Auto digital tuning
- · Antenna: FM Antenna

Sound

- Output power (RMS): 2x1W
- Sound Enhancement: Dynamic Bass Boost
- · Volume Control: rotary
- · Sound System: Stereo
- Speaker diameter: 3"

Loudspeakers

· Built-in speakers: 2





- · Loudspeaker types: Loudspeakers

Connectivity

• Headphone: 3.5 mm

Convenience

- Remote control: 8 keys
- Backlight
- Backlight color: Blue
- Display Digits: 5
- Display Type: LCD

Accessories

- Included accessories: AC Power Cord, User Manual, Warranty certificate
- · Remote control: 1

Dimensions

- Packaging dimensions (W x H x D): 332 x 197 x 280 mm
- Product dimensions (W x H x D): 290 x 151 x 233 mm
- Weight: 2.1 kg
- · Weight incl. Packaging: 2.5 kg

Power

- Battery type: LR14
- Battery voltage: 1.5 V
- · Mains power
- Number of batteries: 8





10 hours of MP3-CD music

Highlights

MP3 stands for "MPEG 1 Audio layer-3".MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

CD-R/RW Compatible

CD-Rewritable Compatible means that your audio set can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players. The laser pick-up and CD decoder circuitry of CD-RW compatible players are specially designed to read the special audio CD-RW phase-change recording layer, ensuring you can always play your home-recorded discs on your audio CD system.

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings from low to high - at the touch of a button! Bottomend bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Autostore programming

Autostore Programming is a convenient feature that allows you to tune in to your favorite stations and set station presets by simply pressing a button. Autostore Programming does away with the hassle of manual radio station tuning and setting of presets. A built-in electrical circuit automatically scans local radio station frequencies, locks on to the strongest radio station signals, and assigns them to specific

Stereo headphone socket

Connect your own headphone for a more personal listening experience whenever you want it. You can enjoy your favorite music in great sound without disturbing others by connecting your headphones to the player.

Handy remote control

Handy remote control



Issue date 2014-02-10

Version: 1.0.4

© 2014 Koninklijke Philips N.V.

All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 9073 101 02641 EAN: 87 10895 96623 8

www.philips.com