



Philips
CD Soundmachine with
Dynamic Bass Boost

PSS010

Sound Takes Shape

Sound takes shape and adds a new dimension to your audio experience. Intrigued by unique design and inspiring innovation, you'll be wowed by unexpected big sound from this small yet potent marvel, which complements your personal space.

A new dimension to your audio experience

- Unique and innovative, 'soft' design
- Small footprint to blend into any lifestyle
- Sophisticated aluminum body

Unexpected power

- Built-in speakers featuring XSL Acoustics for dynamic sound
- Dynamic Bass Boost for deep and dramatic sound

Easy to use

- Touch screen for easy navigation
- Digital tuning with preset stations for extra convenience
- Motorized CD loader for convenience access
- Handy remote control

PHILIPS

Specifications

Sound

- Front Speakers Ways: 2
- Loudspeaker Enhancement: Detachable Cloth Grilles
- Loudspeaker types: Bass Reflex Speaker System
- Magnet type: Neodymium
- Output power (RMS): 2X2W+4W
- Sound Enhancement: Advanced Sound System, Dynamic Bass Boost
- Sound System: Stereo
- Volume Control: digital
- Woofer: 1 inch

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: Fast Forward/Backward, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Motorised
- Programmable Tracks: 20

Tuner/Reception/Transmission

- Antenna: FM Antenna
- Antenna location: External
- Auto digital tuning
- Tuner Bands: FM

Connectivity

- DC in: 10V
- Headphone: 3.5 mm

Convenience

- Backlight
- Backlight color: Blue
- Clock/Version: Digital
- Display Digits: 7
- Display Enhancements: Brightness Control, Function indication, Touch screen control
- Display Type: LCD

Accessories

- AC/DC Adaptor
- Included accessories: User Manual, Warranty certificate
- Remote control: 17 Key

Dimensions

- Packaging dimensions (W x H x D): 413 x 278 x 313 mm
- Product dimensions (W x H x D): 213 x 178 x 213 mm
- Weight: 3.4 kg
- Weight incl. Packaging: 4.4 kg

Power

- Adaptor type: 10V 1200mA



Highlights

Unique and innovative design

Unique and innovative, 'soft' design

Small footprint

Small footprint to blend into any lifestyle

Sophisticated aluminum body

Sophisticated aluminum body

XSL Acoustics

Enjoy dynamic sound and powerful bass performance from your ShoqBox with XSL Acoustics. Impressive sound is produced by combining bright, brisk treble and mid range sound with elastic, powerful bass. Innovative use of high-tech materials like titanium cone and neodymium magnet deliver sound output that's nearly double the power of a traditional speaker driver of the same size. Precise tuning between the speaker driver, the small acoustic architecture and the circuitry ensures superbly dynamic sound and optimizes bass performance from the smallest sound enclosure.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Touch screen

Touch screen control allows you to control your device by simply pressing on-screen buttons rather than physical buttons on the device. Simply power up the device and the touch screen user interface will show up on the LCD display with all the control options for the device. Touch screen control combines LCD display technology with pressure sensors and a powerful digital micro processor. When you press on a specific area of the screen with your finger, the relevant signal is sent to the processor and the command is immediately executed.

Digital tuning with presets

Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

Motorized CD loader

A motorized sliding front door adds even more panache to the already sleek design of this system. The stylish yet functional door housing the disc slides up and down vertically in a smooth motion at the touch of a button whenever you feel like changing your music selection. Just sit back and enjoy the dynamic sound performance while watching the disc play through the transparent window.

Handy remote control

Handy remote control



Issue date 2014-02-10

Version: 4.0.5

12 NC: 9073 101 01418
EAN: 87 10895 83063 8

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com