

Philips
Micro Hi-Fi System

- CD playback
- Compact design

MC147



Superb sound from compact design

Tune in to superb sound from a surprisingly compact design. The MC147 Micro System will enhance your living space while enriching your music listening experience. Just press Play to enjoy room-filling, dynamic bass sounds.

Enrich your sound experience

- Play CD, CD-R and CD-RW discs
- Dynamic Bass Boost for deep and dramatic sound
- Autostop cassette deck
- 4W RMS total output power

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 20 preset stations for extra convenience

Fits any space, any lifestyle

- Compact design that fits anywhere
- Easy-to-use remote control included

PHILIPS

Specifications

Sound

- Output Power: 2x2W RMS
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

Loudspeakers

- Main Speaker: 3" woofer

Audio Playback

- Playback Media: CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program
- Loader Type: Top
- Cassette Deck Technology: Mechanical

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Station presets: 20

Connectivity

- Headphone: 3.5 mm
- Other connections: FM fixed pigtail antenna, MW Antenna
- Audio Connections: 3.5mm Line in

Convenience

- Alarms: Sleep timer
- Clock: On main display
- Display Type: LCD
- Backlight color: Blue

Accessories

- Included accessories: FM/MW Antenna, IFU / User Manual, World Wide Warranty leaflet
- Remote control: 24 key remote control

Dimensions

- Set dimensions (W x H x D): 148 x 233 x 216 mm
- Main speaker dimensions (W x H x D): 134 x 230 x 152 mm
- Packaging dimensions (W x H x D): 370 x 270 x 326 mm
- Weight incl. Packaging: 4.75 kg

Highlights

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Issue date 2013-05-10

Version: 1.0.4

12 NC: 8670 000 33205
EAN: 87 12581 35832 7

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com