

• with AirPlay



**DS9800W** 

# Feel the emotions of a live performance

# with this sound system

Bring life back into music with deep, natural audio delivered by acoustic SoundSphere technologies. Equipped with AirPlay, these elegant Philips DS9800W/10 docking speakers let you stream songs from iPod Touch, iPhone, iPad and iTunes.

#### **Peerless sound quality**

- SoundSphere for a natural, deeper and wider sound impression
- FullSound enhances sound detail for rich and powerful sound
- SoundCurve for superb sound reproduction
- Bass-reflex design for deep, tight bass reproduction
- $2 \times 50$  W RMS total output power

## **Exquisite design and finishing**

- Real hand-crafted wood speaker enclosure for fidelity sound
- External finish polished with lacquer

# **Advanced versatility**

- Stream music with AirPlay wireless technology
- · Docking cradle for charging
- AUX-in for easy connection to almost any electronic device

#### **Intuitive control**

· SoundStudio app for complete control of audio settings



# Highlights

#### **SoundSphere**



Bask in the glory and energy of music as SoundSphere gives you each note as the artist intended. Delivering clear and natural audio, SoundSphere creates a sound impression that is deeper and wider. The result is life-like audio that will make you believe the artists are performing in front of you. Each SoundSphere speaker features a tweeter that hangs above the speaker box. The tweeter is able to emit sound more clearly and in all directions. Precise audio crossover engineering and careful positioning of the woofer to embrace the tweeter ensures minimised interference and even more natural sound.

# **FullSound™**



Philips' proprietary FullSound technology uses latest-generation Digital Signal Processing to faithfully enhance music rendering. Music content is dynamically analysed and optimised to let you experience music with great detail and warmth.

#### **SoundCurve**



The carefully designed curved back cover of this Philips docking speaker creates a highly effective acoustic structure for sound reproduction. Its clean curve enforces the rigidity of the speaker cabinet, dramatically reducing internal resonance and eliminating the vibration and distortion of sound. You get to enjoy superb crystal-clear sound in stunning-looking speakers.

#### Bass-reflex design



Bass-reflex acoustic load uses a bass pipe tuned to the acoustic volume of the speaker box, in order to reproduce deep bass from compact enclosures. The carefully designed profiled bass-pipe helps air flow and allows for deep and impactful bass, even at loud volumes while minimising air turbulence that may cause distortion

# Real hand-crafted wood speaker



Wood has been used throughout history to craft the finest musical instruments. Its natural

acoustic properties continue to make it the material of choice for the best instruments and sound equipment today. Not only is this speaker handcrafted in wood, advanced wood bending techniques have been applied to create the right curvature for the enclosure. The calculated curve reduces vibration and eliminates the distortion of sound, resulting in the delivery of natural, life-like audio.

#### **External finish with lacquer**

These beautiful wood-crafted speakers have been coated with seven layers of lacquer, each applied with care, and polished to a perfect finish. The speaker shares this deeply gleaming look with grand pianos - a refined and elegant look that lends grace and charm to the home.

### AirPlay wireless technology



AirPlay lets you stream your entire iTunes music collection to your Fidelio docking stations. It plays wirelessly from the iTunes program on your computer, iPhone, iPad or iPod Touch to any AirPlay-enabled speaker in your home. All you have to do is ensure your speakers are connected to your Wi-Fi network. AirPlay also lets you play simultaneously on every speaker in every room. Make your favourite tunes follow you into whichever room you go.













# Specifications

#### **Compatibility**

• Compatible with: all iPod, iPhone and iPad

## iPod/iPhone/iPad App

- App name: SoundStudio, Free download from App store
- Compatibility: iPod touch, iPhone, iPad iOS 4.3 or
  later.

## Loudspeakers

- • Speaker drivers: 2 x 3/4" / 20 mm tweeter, 2 x 5" / 12.5cm midwoofer
- Output power (RMS): 2 x 50 W

#### **Accessories**

 Included accessories: Charging cradle, Remote Control, 3.5 mm stereo line-in cable, AC Power Cord, Quick start guide, Warranty certificate, World Wide Warranty leaflet

#### Connectivity

- AirPlay
- Aux in

#### **Dimensions**

- Product dimensions: [speakers] 265 (diameter) x 410 mm
- Packaging dimensions (WxDxH): 760 x 338 x 485 mm
- Product weight: (main unit) 12 kg
- Weight incl. Packaging: 14.5 kg

#### Power

• Power supply: 100-240 VAC, 50/60 Hz



Issue date 2013-05-31

© 2013 Koninklijke Philips N.V. All Rights reserved.

Version: 10.1.15

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 66129 EAN: 87 12581 55629 7

www.philips.com