

Philips  
DVD player

Karaoke

DVP3000K



## See, hear, play everything

Introducing a dream player that promises flawless, true-to-life picture quality and the ability to play virtually any disc! This Philips DVD player delivers your movies and music entertainment experience right in your personal environment.

### Great audio and video performance

- Progressive Scan component video for optimized image quality
- High quality outputs for analog and digital audio

### Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD
- Music: CD, CD-R/RW and MP3-CD
- Photos: Picture CD (JPEG)

### Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

### Your personal karaoke show

- Karaoke for endless singing entertainment

# PHILIPS

# Specifications

## Picture/Display

- Aspect ratio: 4:3, 16:9
- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Smart Picture Setting

## Sound

- D/A converter: 24 bit, 96 kHz
- Signal to noise ratio: 95 dB
- Distortion and Noise (1kHz): 80 dB
- Crosstalk (1kHz): 90 dB
- Dynamic Range (1kHz): 85 dB
- Sound System: Dolby Digital
- Sound Enhancement: 3D Virtual Surround, Night Mode, Smart Sound

## Video Playback

- Playback Media: CD, CD-R, CD-R/CD-RW, Video CD/SVCD, DVD+R, DVD+RW, DVD-R, DVD-RW (Video mode), DVD-Video
- Compression formats: MPEG1, MPEG2
- Video disc playback system: NTSC, PAL

## Audio Playback

- Playback Media: CD, CD-R, MP3-CD, CD-RW
- Compression format: PCM, MP3
- MP3 bit rates: 32 - 256 kbps

## Still Picture Playback

- Playback Media: Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom, Slideshow

## Connectivity

- Front / Side connections: Microphone
- Other connections: ComponentVideo out, Progressive, Composite video (CVBS) out, Analog audio Left/Right out, Digital coaxial out

## Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: English, Malay, Simplified Chinese, Traditional Chinese, Korean, Thai
- Karaoke: MIC volume

## Power

- Power supply: 110-240V, 50/60 Hz
- Power consumption: 10 W
- Standby power consumption: < 0.8 W

## Accessories

- Batteries: 2 x AA
- Remote control: 3141 017 90181
- Cables: 1 x AV Cables
- User Manual: English, Simplified Chinese, Traditional Chinese, B. Melayu
- Warranty Card

## Dimensions

- Set dimensions (W x H x D): 360 x 37 x 265 mm
- Set weight: 1.98 kg
- Packaging dimensions (W x H x D): 415 x 82 x 352 mm
- Weight incl. Packaging: 2.98 kg

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Multi-format Movies

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

## Multi-format Music

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.

## Picture CD (JPEG)



Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

## Ultra-slim design

The attractive enclosure has a very low profile.

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



Issue date 2014-02-10

Version: 9.0.10

12 NC: 8622 810 12069  
EAN: 87 10895 85290 6

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)