



Philips
PhotoFrame

7" LCD

16:9 frame ratio

SPF1007



Share your memories

How many digital pictures are hidden on your PC? See, share, organise and relive your memories with Philips PhotoFrame™, the easiest way to share your memories by displaying your digital photos in stunning quality - without a PC.

Top-quality display for print-like pictures

- imagen for sharp and vibrant colour
- Add new glow to old memories with RadiantColor
- SmartContrast: For incredible rich black details

Easily display and manage your digital photos

- Have fun with collages: display multiple photos in one view
- View USB flash drive photos without a PC

Green design

- Auto turning display on/off at pre-set times for power saving

Simple and clean design complements your photos

- Tasteful glossy finish and great feel

PHILIPS
sense and simplicity

Highlights

imagen technology

imagen is exclusive Philips photo enhancement technology that automatically analyses your photos to correct colour and adjust for optimal contrast: imagen separates colours to avoid "crosstalk", adjusts brightness distribution for great visual contrast and corrects Gamma for colour accuracy.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the colour on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

SmartContrast



SmartContrast is Philips technology that analyses the contents you are displaying, automatically adjusting colours and controlling backlight intensity to dynamically enhance contrast for the best digital images and optimum contrast for better entertainment when viewing videos or playing games where dark hues are displayed; when you select the Economy mode, contrast is adjusted and backlighting fine-tuned for just-right display of

everyday office applications and lower power consumption.

Multiple-photo collage effect

It's a slideshow effect to show photos in collage form, which automatically and randomly compiles different photos together, eliminating unattractive borders that may result from photos that are smaller than the screen size.

Viewing photos in USB flash

A USB connector for easy viewing and sharing of photos stored on a USB flash drive.

SmartPower

A timer turns PhotoFrame on and off at the times you choose, reducing energy consumption for the sake of our environment and saving up to one third of your PhotoFrame energy costs.



Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H)/100° (V)
- Lifetime, to 50% brightness: 20,000 hr
- Aspect ratio: 16:9
- Panel resolution: 480 x 234
- Brightness: 140 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host

Storage Media

- USB: USB flash drive
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro

Convenience

- Card Reader: Built-in (1 x)
- Photo format supported: JPEG photo, Up to 10 MB JPEG files, Up to 20 Megapixels, BITMAP, GIF, TIFF
- Placement supported: Landscape, Portrait
- Buttons and controls: 7 buttons
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Photo edit: Copy, Delete, Rotate, Zoom and crop
- Photo effects: Black and White, Frames, Radiant colour
- Slideshow setting: Random, Sequential, Transition effect
- Screen background: Black, White, Grey
- Setup function: Brightness adjustment, Language, Status, Auto on/off, Set time and date, Clock display enable/disable
- System status: Firmware version, Remaining memory
- Connected media status: Connected media, Remaining memory
- Plug and Play Compatibility: Windows Vista, Windows 2000/XP or later, Mac OS X
- Regulatory Approvals: CE
- On-Screen Display languages: English, Spanish, German, French, Italian, Dutch, Danish, Simplified

Chinese

Accessories

- Included Accessories: AC-DC Adapter, Stand, Quick start guide, User Manual

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 35°C
- Temperature range (storage): -20°C to 70°C

Power

- Power mode supported: AC powered

Packaging dimensions

- Packaging dimensions (W x H x D): 24 x 19 x 9.5 cm
- Packaging dimensions (W x H x D): 9.4 x 7.5 x 3.7 inch
- Net weight: 0.9 kg
- Net weight: 1.984 lb
- Gross weight: 1.1 kg
- Gross weight: 2.425 lb
- Tare weight: 0.2 kg
- Tare weight: 0.441 lb
- EAN: 87 12581 46688 6
- Number of products included: 1
- Packaging type: Box

Outer Box

- Outer carton (L x W x H): 29.5 x 24.8 x 19.8 cm
- Outer carton (L x W x H): 11.6 x 9.8 x 7.8 inch
- Net weight: 2.7 kg
- Net weight: 5.952 lb
- Gross weight: 3.6 kg
- Gross weight: 7.937 lb
- Tare weight: 0.9 kg
- Tare weight: 1.984 lb
- GTIN: 1 87 12581 46688 3
- Number of consumer packages: 3



Issue date 2010-04-07

Version: 2.1.5

12 NC: 8670 000 49985
EAN: 87 12581 46688 6

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com