

Philips  
Surge protector

**PowerSquid**

5 outlets

**SPR5500BN**



## General Purpose Power Protection

918 Joules/36,000 Ampere

This surge protector offers flexible power. Engineered to be the most sophisticated and complete power multiplier, its flexible arms transform the static power strip into a dynamic power delivery device.

### **Built-in convenience**

- Power indicator light
- Protection indicator light
- Right angle plug
- 1 m power cord

### **Dependable protection**

- £50,000 equipment warranty
- V3 Advanced Surge Technology
- Power blocker
- 40 dB EMI/RFI noise filtration
- Master on/off switch

### **Ideal for office equipment, appliances and more**

- 5 flexible outlets

**PHILIPS**  
sense and simplicity

# Specifications

## Packaging dimensions

- Packaging dimensions (W x H x D):  
17.1 x 48.3 x 10.2 cm
- Net weight: 1.111 kg
- Gross weight: 1.27 kg
- Tare weight: 0.159 kg

## Outer Carton

- Outer carton (L x W x H): 50.5 x 19.1 x 32.7 cm
- Net weight: 3.333 kg
- Gross weight: 3.856 kg
- Tare weight: 0.523 kg

# Highlights

## 5 flexible outlets

Five outlets on separate cords that are all adapter-spaced accommodate multiple devices without crowding.

## £50,000 equipment warranty

Protects your connected equipment for the life of the product.

## V3 Advanced Surge Technology

This new surge protection technology provides 27% greater surge protection capacity and better heat dissipation for safe, more reliable and longer-lasting surge protection.

## Power blocker

This automatic shutdown technology senses when the device has reached capacity and automatically shuts down electricity to your equipment. It protects against subsequent surges, even if you are not present

## 40 dB EMI/RFI noise filtration

Built-in filtering technology ensures the best performance from your components. It guards against signal interference and loss of data. The higher the dB rating the better the noise reduction.

## Master on/off switch

This master switch controls power to the outlets on the surge protector.

## Power indicator light

This LED alert lights up to indicate that the surge protector is drawing power from the AC outlet.

## Protection indicator light

This LED alert lights up to indicate the surge protector is working properly.

## 1 m power cord

Provides power to the unit which can be 1 m from the AC outlet.



Issue date 2011-04-05

Version: 1.0.7

12 NC: 8670 000 35637  
EAN: 87 12581 38395 4

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)