

Philips Sleek micro sound system

DAB

**MCB275** 

# Obsessed with sound

## Sound that fits your home

Enjoy superb clarity with built-in DAB tuner with this Philips sleek micro music system. With MP3-CD playback, have the freedom to personalise your sound settings to your tastes. Coupled with wall mounting flexibility, this system will leave you awed.

### Enjoy digital quality DAB radio

- Tune into digital-quality radio stations
- DAB and FM compatible for a complete radio experience

### Unlimited listening pleasure

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW

### **Enrich your sound experience**

- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound

### Start the day your way

- Digital tuning with 20 pre-set stations for extra convenience
- Wake-up and sleep timer functions



# Highlights

### **DAB** and **FM** compatible

DAB (Digital Audio Broadcasting) digital radio is a new way of broadcasting radio, in addition to FM analogue transmission, via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear, crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB digital stations there are no frequencies to remember, and sets are tuned by station name, so there is no retuning on the move.

### **Digital Sound Control**

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls

you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

### **Dynamic Bass Boost**

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a

button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

### **USB Direct for MP3/WMA music**

Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.

















# Specifications

#### Sound

- Output power: 2 x 5 W music power
- Sound enhancement: digital sound control 4 modes, Dynamic Bass Boost

### Loudspeakers

- Speaker drivers: 3" woofer
- · Speaker types: bass reflex speaker system

### Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/programme
- Others: ID3-tag support
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, programme play, repeat, shuffle, stop

### Tuner/Reception/Transmission

- DAB: info display, menu, smart scan
- Tuner bands: FM stereo, DAB (Band III)
- RDS: station name, programme type, radio text
- Station presets: 20
- Antenna: fixed FM and DAB T-shape antenna
- Tuner enhancement: auto digital tuning, auto scan

### **Connectivity**

• Audio/Video output: Headphone (3.5 mm)

- MP3 Link: 3.5 mm stereo line in
- USB: USB host

### Convenience

- · Alarms: CD alarm, radio alarm
- Clock: on main display, sleep timer
- · Loader type: front, motorised
- Display type: LCD display (dot matrix)
- Backlight colour: Blue

#### Accessories

- Remote control: 40-key with lithium battery
- Others: DAB antenna, screws for wall mounting x
- Warranty: Worldwide Guarantee booklet

### **Dimensions**

- · Gross weight: 5.6 kg
- Main speaker dimensions (W x D): 166 x 90 mm
- Main speaker height: 245 mm
- · Main unit depth: 96 mm
- Packaging width: 330 mm
- · Main unit height: 245 mm
- Packaging height: 313 mm
- Main unit width: 250 mm
- · Packaging depth: 303 mm

#### Green

• Eco Power standby: 1 W



Issue date 2017-08-04

Version: 1.0.7

© 2017 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 000 30779 EAN: 87 12581 34010 0

www.philips.com