

Philips Design collection  
Cordless phone with  
answering machine

### Slim line

2 handsets  
Black

ID5552B



## Design collection

When beauty is the call, the ID555 is the answer. This "Design collection" phone is made to delight senses with its elegant slim lines and a pure sound to match. The ID555 is the perfect addition to the most exclusive home interior.

#### Exclusive design

- Stylish black glossy finish
- Extra slim design

#### Never miss a call

- Digital answering machine
- 30-minute recording time
- Message-counter on Base

#### Pure convenience

- Bright blue illuminated display & keypad
- 200-name phonebook
- Speakerphone - Talk handsfree

#### Eco-designed

- Very low energy consumption
- Automatic reduction of the emitted power

# Specifications

## Picture/Display

- Backlight
- Backlight color: Blue
- Display colors: Black & White
- Lines of text: 5
- Main Display Technology: FSTN
- Main Display Type: Full Graphic

## Sound

- Handset ringers: Polyphonic
- Volume Control: Volume Control up/down

## Convenience

- Alarms: Alarm Clock
- Base Station keys: Answering machine keys, Paging key
- Battery charging indication
- Call Management: Call Waiting\*, Caller ID\*, Conference Call, Explicit Call Transfer, Microphone mute
- Ease of Use: Keypad Lock, Menu Control
- Function: Easy Call
- Multi base capability: 1
- Multi handset capability: Up to 5 handsets
- Signal strength indication
- VIP group with own melody: Yes for each phonebook entry
- Backlit keypad: Yes (Blue)
- Speakerphone - talk handsfree

## Network Features

- Antenna: Integrated on base, Integrated on handset
- Compatible: GAP
- Dialing: Tone, Pulse

## Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

## Answering Machine

- Plug & Play Answering machine
- Recording time capacity: Up to 30 min.
- Message counter on base

## Memory Capacity

- Call log entries: 50
- Phonebook: 200 names and numbers
- Redial List Capacity: 10

## Dimensions

- Base dimensions: 128 x 69 x 85mm
- Handset dimensions: 144 x 43 x 14.5mm

## Power

- Battery Capacity: 500 mAh
- Kind of Battery: Rechargeable
- Mains power: AC 220-240V - 50Hz
- Number of batteries: 1 battery-pack per handset
- Standby time: Up to 130 hours
- Talk time: Up to 10 hours

# Highlights

## Speakerphone - Talk handsfree

Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

## Very low energy consumption

Thanks to a high efficiency power supply, the overall energy consumption is reduced by more than 50% compared to a conventional power supply.

## Automatic power reduction

Thanks to an intelligent embedded system, the transmitted power is permanently controlled and optimized depending on the distance between handset and base unit.



Issue date 2019-06-11

Version: 2.0.6

12 NC: 8670 000 41202  
EAN: 87 12581 43406 9

© 2019 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)