



Philips  
Soundbar 2.1 with wireless  
subwoofer

2.1 CH wireless subwoofer  
HDMI ARC  
Dolby Audio  
140 W



TAB6305



## Ultra slim. Big on sound.

Got a TV that sits on a low stand? This ultra-slim soundbar is low enough to sit under almost any TV and comes with a wireless subwoofer. You get sound that's big enough to bring your favourite shows, films and music to life.

### Ultra-low profile. Richer, deeper, clearer sound.

- 2.1 channels. Wireless subwoofer for deeper bass
- Dolby Audio. Be at the heart of the action
- Ultra-slim design. Fits under almost any TV
- Robust metal grille for clear sound

### Music and movies

- Connect your favourite sources for bigger sound
- Audio-in. Optical in. Bluetooth
- HDMI ARC. Control the soundbar with your TV remote
- IR repeater included, with pass-through cable

### See it. Hear it. Love it.

- Place on your TV table, the wall or any flat surface
- Integrated wall brackets
- Soundbar dimensions: 650 x 35 x 81 mm
- Subwoofer dimensions: 120 x 402 x 300 mm

# PHILIPS

# Specifications

## Loudspeakers

- Main unit speaker drivers: L: mid-range driver + tweeter; R: mid-range driver + tweeter
- Subwoofer type: Wireless subwoofer, Active
- Subwoofer drivers: 1 x low frequency
- External subwoofer enclosure: Bass reflex

## Connectivity

- Integrated Connections: Bluetooth
- Rear Connections: Digital optical in, HDMI 1.4 output (ARC), USB, Audio-in 3.5 mm jack, IR OUT 2.5 mm jack
- HDMI features: EasyLink (HDMI-CEC)
- Wireless connections: Bluetooth 4.2
- Bluetooth: Receiver

## Sound

- Speaker system output power: 288 W max/140 W RMS (10% THD)

## Convenience

- EasyLink (HDMI-CEC): Audio Return Channel, Automatic audio input mapping, One touch standby, Remote Control-Passthrough
- Night mode: No

## Design

- Colour: Dark grey
- Wall mountable

## Power

- Auto standby
- Standby power consumption: Main unit: <0.5 W; Subwoofer: <0.5 W
- Main unit power consumption: 18 W
- Main unit power supply: 100-240 V AC, 50/60 Hz
- Subwoofer power consumption: 20 W
- Subwoofer power supply: 100-240 V AC, 50/60 Hz

## Dimensions

- Main Unit (W x H x D): 650 x 35 x 81 mm
- Subwoofer (W x H x D): 120 x 402 x 300 mm

## Accessories

- Included accessories: 1 x CR2025 Battery, Power cord, Power adapter, Remote Control, Wall mount bracket, Quick start guide, World Wide Warranty leaflet
- IR repeater: Yes, with pass-through cable and bracket

## Supported Audio Formats

- HDMI ARC: Dolby Digital, LPCM 2ch
- Optical: Dolby Digital, LPCM 2ch
- Bluetooth: SBC
- USB: MP3, WAV, FLAC

## Packaging dimensions

- EAN: 48 95229 10859 2
- Packaging dimensions (W x H x D): 73.5 x 42.5 x 14.5 cm
- Gross weight: 8 kg
- Net weight: 5.9 kg
- Number of products included: 1
- Packaging type: Box
- Tare weight: 2.1 kg
- Type of shelf placement: Laying

## Outer Carton

- GTIN: 1 48 95229 10859 9
- Number of consumer packages: 2
- Gross weight: 17 kg
- Outer carton (L x W x H): 75.5 x 31.5 x 45.5 cm
- Net weight: 11.8 kg
- Tare weight: 5.2 kg

# Highlights

## 2.1 channels

The thunder of explosions. The roar of a crowd. 2.1 channels bring richer, deeper, clearer sound to your favourite films and shows. The compact wireless subwoofer delivers rich bass.

## Ultra-slim design

This soundbar has a profile of just 35 mm, making it perfect for TVs with lower stands. When it comes to placement, the integrated wall brackets keep your options open. The compact design of the powerful subwoofer makes it easy to conceal.

## Dolby Audio

Be immersed in your favourite shows and films. This soundbar with wireless subwoofer supports the Dolby Digital format for a more expansive and involving experience. Voices will be clearer. Effects will be more impressive.

## HDMI ARC

This soundbar connects to your TV via HDMI ARC, allowing you to control soundbar volume with the same remote that you use for your TV. The included IR repeater lets you use your TV remote even if you place the soundbar in front of the TV's IR sensor.

## Connect your favourite source

Stream playlists from your mobile device via Bluetooth. Connect audio sources via audio-in, optical input or USB. Whatever you love, it will sound great through this soundbar.



Issue date 2021-08-11

Version: 9.2.3

12 NC: 8670 001 66883  
EAN: 48 95229 10859 2

© 2021 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)