



Philips Perfect replacement
Universal remote control

4 in 1

SRP3004



Quick and Easy Setup

Experience a quick and easy setup with your Philips universal remote control with its innovative SimpleSetup. With the XL buttons and the protective rim, it is easy to use and great for replacing old, lost or broken remotes.

Ideal replacement for your old remote

- 4-in-1 remote for your TV, DVD player/recorder, STB and VCR
- Ready for use with Philips equipment

Easy to use

- SimpleSetup is an exclusive feature of Philips
- Protective rim increases comfort and gives a firm grip
- Big buttons increase operability and readability.

Full compatibility with your devices

- Compatible with more than 1000 brands

Consumer care

- URC support service via dedicated website



asimpleswitch.com



asimpleswitch.com

PHILIPS

Specifications

Convenience

- DVD functions: Transport keys, System menu control, Disc menu control, Digit keys, Subtitle select, Audio settings
- Language support: EN/FR/DE/IT/ES/NL/DK/SV/NO/FI/PT/TR
- Number of keys: 31
- Pre-programmed for Philips
- Regulatory approvals: CE Mark
- SAT/CBL functions: Digit keys, Menu Control, Guide, info, Text functions, Channel up/down, Volume up/down, mute
- Shock proof
- Splash-proof
- TV functions: Programme up/down, Volume up/down, mute, Power/standby, Digit keys, AV selection, external, Menu Control, Colour/Brightness control, Teletext keys, Fast text keys
- Supported devices: TV, VCR, DVD, SAT
- VCR functions: Transport keys (6), Showview, VCR plus, Menu Control

Power

- Battery type: AAA

Infrared Capabilities

- Operating distance: 33 ft (10 m)

- Transmitting LEDs: 1
- Universal IR code database
- Number of brands in database: Over 1000
- Carrier frequency range: 24–55 kHz
- Transmission angle: 45 degree

Packaging dimensions

- Packaging dimensions (W x H x D): 14.5 x 27.5 x 3 cm
- Net weight: 0.171 kg
- Gross weight: 0.207 kg
- Tare weight: 0.036 kg
- EAN: 87 12581 48925 0
- Number of products included: 1
- Packaging type: Blister
- Type of shelf placement: Hanging

Outer Carton

- Outer carton (L x W x H): 29.9 x 16.9 x 19.4 cm
- Net weight: 1.026 kg
- Gross weight: 1.724 kg
- Tare weight: 0.698 kg
- GTIN: 1 87 12581 48925 7
- Number of consumer packages: 6

Setup

- Setup Method: SimpleSetup

Highlights

4-in-1 remote control

Replace a table full of remote controls with one robust unit that operates your TV, DVD player/recorder, satellite receiver, digital terrestrial receiver or cable set-top box (STB) and VCR, regardless of the brand or model.

Big buttons

Big buttons are larger size buttons on a remote to help read the label better. Additionally, pressing the button becomes more convenient, as the size has increased by 2 mm compared to the standard button remote size.

Online URC support service

Dedicated support service for your remote control whereby all codes for all brands are available via the Philips URC website.

SimpleSetup

Setup your universal remote control fast and easily thanks to the innovative SimpleSetup feature which only requires 3 simple steps: 1. Look up the brand code for your device and enter it into the remote 2. Press the on/off button until your device goes off 3. Check that all keys are working. Ready!



Issue date 2017-04-10

Version: 3.0.9

12 NC: 8670 000 53796
EAN: 87 12581 48925 0

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com