

Philips
DVD Micro Theater

DivX playback
component design

MCD139B



Turn any room into theater

Enjoy your favorite movies with The Philips MCD139B. Featuring Progressive Scan for optimized image quality and Dynamic Bass Boost for powerful sound output, you can now enjoy cinematic experience right at your home!

Enjoy your favorite movies, photos and music

- Progressive Scan component video for optimized image quality
- Dolby Digital for ultimate movie experience
- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD

Enrich your sound experience

- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- Total 100W RMS

Start the day your way

- Wake up and sleep timer functions
- Digital tuning with 40 preset stations for extra convenience

PHILIPS

Highlights

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.



Specifications

Sound

- Output Power: 2x25W + 50W RMS / 1800W PMPO
- Sound Enhancement: Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital

Loudspeakers

- Main Speaker: 3" woofer
- Subwoofer type: Passive

Video Playback

- Playback Media: DVD+RW, DVD-Video, Picture CD, Video CD/SVCD, DivX, DVD
- Disc Playback Modes: Angle, PBC, Slow Motion, Zoom, OSD, Resume Playback from Stop, Parental control, A-B Repeat
- Video Enhancement: Progressive Scan
- DVD Region.: 4

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD, CD-R, CD-RW
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Loader Type: Top

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analog: Component Y Pb Pr

- (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Aux in: 1x(L/R)/ RCA
- Other connections: Digital audio coaxial out, FM Antenna, Line out, DIN connection
- Audio Connections: 3.5mm Line in

Convenience

- Alarms: Sleep timer, CD Alarm, Radio Alarm
- Clock: On main display
- Display Type: White FTD
- OSD Languages: Spanish, English, Portuguese

Accessories

- Included accessories: Composite video cable (Y), FM antenna, IFU / User Manual, Quick Use Guide, World Wide Warranty leaflet, AC Power Cord
- Remote control: 38-key with Lithium battery
- Cables: Din
- User Manual: English, Spanish, Brazilian-Portuguese
- Quick start guide: Spanish, Br-Portuguese, English

Dimensions

- Set dimensions (W x H x D):
218 x 90 x 221.5 mm
- Main speaker dimensions (W x H x D):
125 x 250 x 232 mm
- Packaging dimensions (W x H x D):
550 x 330 x 314 mm
- Subwoofer dimensions (W x H x D):
147 x 250 x 232 mm
- Weight incl. Packaging: 10 kg

Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2014-02-05

Version: 3.0.2

12 NC: 8670 000 37287
EAN: 87 12581 39769 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Avoid extensive use of the set in a volume higher than 85 decibel
because this may damage your hearing.