

Philips
DVD home theatre system



HTS3367



High definition video and surround sound

with tower speakers

High definition pictures and surround sound delivered by this system provide amazing home entertainment. Enjoy crisp pictures with 1080p HDMI upscaling, and playback from USB drives, portable media players and virtually any sort of disc.

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays media from USB flash drives

Brings audio and video to life

- HDMI 1080p upscales to high definition for sharper pictures
- DTS, Dolby Digital and Pro Logic II surround sound
- 12-bit/108 MHz video processing for sharp, natural images

Plays all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

Easy to set up and use

- EasyLink for easy control of connected devices via HDMI CEC
- Floor standing speakers for freedom of placement

PHILIPS
sense and simplicity

Highlights

HDMI 1080p



HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multi-channel audio, without conversions to analogue - delivering perfect picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your

USB device, select the movie, music or photo and play away.

DivX Ultra Certified

With DivX support, you can enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files such as movies, trailers and music videos on media, e.g. CD-R/RW and DVD recordable discs. DivX Ultra combines DivX playback with great features including integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

EasyLink

EasyLink lets you control multiple devices with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC-enabled

equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

Plays it all

Play virtually any media format you want - whether they are WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability and the luxury of sharing media files on your TV or home theatre system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they are CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.

12-bit/108 MHz video DAC

12-bit Video DAC is a superior Digital-to-Analogue Converter that preserves every detail of the authentic picture quality. It shows subtle shades and smoother graduation of colours, resulting in a more vibrant and natural picture. The limitations of the standard 10-bit DAC become particularly apparent when it is used with large screens and projectors.

Floor standing speakers

Floor standing speakers for freedom of placement



Specifications

Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 0 x 0 x 0 cm
- Weight: 0 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 97 x 43.5 x 41 cm
- Net weight: 18.986 kg
- Gross weight: 22.491 kg
- Tare weight: 3.505 kg
- EAN: 87 12581 38939 0
- Number of products included: 1
- Packaging type: Box

Outer Box

- Outer carton (L x W x H): 97 x 41 x 43.5 cm
- Net weight: 18.986 kg
- Gross weight: 22.491 kg
- Tare weight: 3.505 kg
- EAN: 87 12581 38939 0
- Number of consumer packages: 1

Picture/Display

- D/A converter: 12-bit, 108 MHz
- Picture enhancement: High Def (720p, 1080i, 1080p), Progressive Scan, Video Upscaling (720p, 1080i/p)

Sound

- Total Output Power: 600 W
- Output power (RMS): 4 x 75 W, 2 x 150 W
- D/A converter: 24-bit, 192 kHz
- Frequency response: 150-18000 Hz
- Signal to noise ratio: >65 dB
- Sound System: DTS, Dolby Digital, Dolby Prologic II, Stereo
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode
- Equalizer settings: Action, Rock, Classic, Concert, Drama, Lounge, Gaming, Sports

Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV, MPEG4
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: Audio CD, DVD+R/+RW, DVD-R/-RW, CD-R/RW
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture compression format: JPEG
- Playback Media: CD-R/RW, DVD+R/+RW, DVD-R/-RW, USB flash drive
- Picture enhancement: Rotate, Zoom, Slideshow

with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- No. of pre-set Audio Channels: 40
- RDS: Station Name

Connectivity

- Front/Side connections: Hi-Speed USB, MP3 Line-in
- Rear Connections: HDMI output, Composite video (CVBS) output, S-Video out, Scart, Digital coaxial in, AUX in, Component Video output, FM Antenna, Easy-Fit speaker connectors

Power

- Power supply: 50 Hz, 230 V
- Standby power consumption: < 1 W
- Power consumption: 100 W

Loudspeakers

- Satellite Speaker: 2 Floor standing pillars
- Satellite speaker drivers: 3" full-range woofer
- Satellite speaker impedance: 3 ohm
- Satellite speaker freq range: 150-20,000 Hz
- Centre Speaker: Magnetically shielded, 3-way
- Centre speaker drivers: 1 x 2" tweeter, 2 x 2.5" woofers
- Centre speaker impedance: 6 ohm
- Centre freq range: 150-20,000 Hz
- Subwoofer driver: 6.5" high-efficiency woofer
- Subwoofer impedance: 6 ohm
- Subwoofer freq range: 40-150 Hz
- Subwoofer type: Passive

Accessories

- Included Accessories: Remote Control, 2 x AAA Batteries, Scart Cable, FM antenna, Quick start guide, User Manual, World Wide Warranty leaflet

Dimensions

- Set dimensions (W x H x D): 435 x 58 x 360 mm
- Set weight: 3.7 kg
- Front Speaker Width: 103 mm
- Front Speaker Height: 203 mm
- Front Speaker Depth: 71 mm
- Front Speaker Weight: 0.45 kg
- Rear Speaker Width: 262 mm
- Rear Speaker Height: 1199 mm
- Rear Speaker Depth: 264 mm
- Rear Speaker Weight: 3.29 kg
- Center speaker dimensions (W x H x D): 440 x 105 x 71 mm
- Centre Speaker Weight: 1.29 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 5.08 kg
- Packaging dimensions (W x H x D): 970 x 435 x 410 mm
- Weight incl. Packaging: 22.4 kg



Issue date 2009-04-12

Version: 2.0.15

12 NC: 8670 000 36328
EAN: 87 12581 38939 0

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com