

Philips
DVD Micro Theater



MCD510

DVD, MP3-CD and WMA-CD playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD and MP3-CD/WMA-CD playback! Relax to your fave movies and music. Home entertainment will never be the same again!

Enjoy your favorite movies, photos and music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital, DTS Digital Out
- 10 hours of MP3-CD or 20 hours of WMA-CD music

Enrich your sound experience

- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 2x25W RMS/1000W PMPO

Start the day your way

- Wake up and sleep timer functions
- Logic tape deck
- Digital tuning with 40 preset stations for extra convenience

Your personal karaoke show

- Karaoke for endless singing entertainment

PHILIPS

Highlights

MP3-CD or WMA-CD playback

MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. A single CD can store up to 10 hrs of music. MP3 has become the standard audio compression format, allowing quick and easy audio file transfer. Windows Media Audio (WMA) is a highly compressed digital audio format from Microsoft that delivers great sound with music files that take up half the disk space and download in half the time. A single CD can store up to 20 hours of good quality WMA music recorded at a bit rate of 64 Kbps.

Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left

and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



Specifications

Sound

- Sound Enhancement: Incredible Surround, Digital Sound Control 4 modes, Dynamic Bass Boost
- Sound System: Dolby Digital, DTS Digital Out
- Output Power: 2x25 watts RMS, 1000 watts PMPO

Loudspeakers

- Main Speaker: 2 way, 4" woofer, Bass Reflex Speaker System, Piezo tweeter, Speaker grilles detachable

Video Playback

- Playback Media: DVD+RW, DVD-Video, Video CD/SVCD, Picture CD
- DVD Region.: 3
- Disc Playback Modes: Zoom, Slow Motion, Resume Playback from Stop, A-B Repeat

Audio Playback

- Playback Media: WMA-CD, MP3-CD, CD-R, CD-RW, CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- ID3-tag support
- Loader Type: Top
- Cassette Deck Technology: Logic
- Cassette Playback Modes: Electronic Speed Control, Full Auto Stop, Tape Counter

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording, Timer for recording from tuner, Automatic Recording Level

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW

- Auto digital tuning
- Station presets: 40
- Tuner Enhancements: Auto Store

Connectivity

- Video Output - Analog: Component Y Pb Pr (cinch), Composite CVBS (yellow cinch), S-Video (on Hosiden)
- Other connections: Active subwoofer Pre-out, Digital coaxial out, Line out, FM Antenna, MW Antenna
- Aux in: 2x(L/R)/ RCA
- Headphone: 3.5 mm

Convenience

- Karaoke: MIC volume, Key control, Echo control
- Alarms: Sleep timer
- Clock: On main display
- Display Type: VFD display
- OSD Languages: English, French, Spanish, Portuguese, Chinese
- Eco Power Standby: 1 watt

Accessories

- Included accessories: Composite video cable (Y), Audio Cable, FM/MW Antenna
- Remote control: 45-key with 2xAA batteries

Dimensions

- Set dimensions (W x H x D): 175 x 254 x 315 mm
- Main speaker dimensions (W x H x D): 175 x 254 x 214 mm
- Packaging dimensions (W x H x D): 408 x 348 x 524 mm
- Weight incl. Packaging: 12.9 kg



Issue date 2014-02-10

Version: 4.0.5

12 NC: 9073 100 12987
EAN: 87 10895 92294 4

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com