



## Philips CD Soundmachine

- 5W
- CD ripping
- Digital tuning



AZ1880

# Enjoy cool sounds in style

The Philips CD soundmachine will free your favorite digital tunes from your portable music player and let you enjoy them all in powerful sound - anytime, anywhere. Features USB Direct and 1-touch MP3 digital recording - no PC required.

### Enjoy your music from multiple sources

- USB Direct for MP3/WMA music playback
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

### Easy to use

- CD ripping for one-touch MP3 digital recording
- Handy remote control for extra convenience
- Stereo headphone jack for better personal music enjoyment

### Powerful sound you can hear and feel

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Dynamic Bass Boost for deep and dramatic sound



asimpleswitch.com



asimpleswitch.com

# PHILIPS

# Highlights

## CD ripping



Simply plug in your USB mass storage device to the USB port on Philips audio system and start recording your favorite music from CDs to your USB device or MP3 player - with one touch operation and no computer needed.

## USB Direct



With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

## Play MP3/WMA-CD, CD and CD-RW



Audio compression technology allows large digital music files to be reduced up to 10 times in size without radically degrading their audio quality. MP3 or WMA are two of the compression formats that let you enjoy a world of digital music on your Philips player.

Download MP3 or WMA songs from authorized music sites on the Internet or create your own MP3 or WMA music files by ripping your audio CDs and transferring them onto your player.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

## Digital tuning with presets



Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Handy remote control



With a handy remote control for greater convenience at your fingertips, all you have to do is sit back and relax.

## Bass Reflex Speaker System



Bass Reflex Speaker System delivers a deep bass experience from a compact loudspeaker box system. It differs from a conventional loudspeaker box system in the addition of a bass pipe that is acoustically aligned to the woofer to optimize the low frequency roll-off of the system. The result is deeper controlled bass and lower distortion. The system works by resonating the air mass in the bass pipe to vibrate like a conventional woofer. Combined with the response of the woofer, the system extends the overall low frequency sounds to create a whole new dimension of deep bass.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.



# Specifications

## Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: fast forward/backward, next/previous album search, next/previous track search, repeat/shuffle/program

## Connectivity

- USB: USB host
- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

## Tuner/Reception/Transmission

- Antenna: FM antenna
- Tuner bands: FM, MW
- Station presets: 40
- Tuner enhancement: auto digital tuning

## Sound

- Sound enhancement: Dynamic Bass Boost
- Sound system: stereo
- Volume control: up/down
- Output power: 2 x 2.5 W

## Loudspeakers

- No. of built-in speakers: 2
- Loudspeaker enhancement: bass reflex speaker system

## Convenience

- Display Digits: 6

- Display type: LCD display
- Backlight color: blue

## Accessories

- Cables/Connection: 3.5 mm stereo line in cable
- Remote control: 12-key with lithium battery
- Others: User Manual
- Warranty: Warranty Certificate

## Dimensions

- Gross weight: 3.5 kg
- Packaging width: 561 mm
- Packaging height: 275 mm
- Packaging depth: 159 mm
- Weight: 2.85 kg
- Main unit depth: 132 mm
- Main unit height: 214 mm
- Main unit width: 451 mm

## Power

- Battery type: C size (LR14)
- Number of batteries: 6
- Power supply: 220 - 240 V
- Battery voltage: 1.5 V

## Audio recording

- Recording media: USB device
- USB recording modes: instant record, programmed tracks, single disc, single track
- USB recording sources: CD



Issue date 2013-05-10

Version: 1.0.4

12 NC: 8670 000 49775  
EAN: 87 12581 46568 1

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)