



Philips
docking entertainment
system

- Dock for iPod/iPhone/iPad
- DAB+

DCB352



Obsessed with sound

Stylish docking station

Free your iPod/iPhone/iPad music and enjoy it in superb sound on the Philips DCB352 Docking Entertainment System. Stylishly designed with a cool metallic finish, the system features DAB+ and boasts 30 W RMS power for truly dynamic sound.

Enjoy digital quality DAB radio

- Clear and crackle-free DAB+ radio
- DAB and FM compatible for a complete radio experience

Enjoy your music from multiple sources

- Play and charge your iPod/iPhone/iPad
- Play MP3/WMA-CD, CD and CD-RW
- Enjoy MP3/WMA music directly from your portable USB drives
- MP3 Link for portable music playback

Enrich your sound experience

- 30 W RMS total output power
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings

Design that blends into your interior

- Elegant design with super-slim CD slot
- Stylish desktop design with high-end metallic front panel

PHILIPS

Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Clear, crackle-free DAB+ radio



DAB+ (Digital Audio Broadcasting) digital radio is, on top of FM analogue transmission, a new way of broadcasting radio via a network of terrestrial transmitters. It provides listeners with more choices and information delivered in clear and crackle-free sound quality. The technology allows the receiver to lock on to the strongest signal it can find. With DAB+ digital stations there are no frequencies to

remember, and sets are tuned by station name, so there is no retuning on the move.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

Play and charge iPod/iPhone/iPad



Enjoy your favourite MP3 music while charging your iPod/iPhone/iPad! The dock lets you connect your portable device directly to the Philips system so you can listen to your favourite music in superb sound. It also charges your iPod/iPhone/iPad while it plays so you can enjoy your music and not have to worry about your portable player battery running out. The

system automatically charges your portable device while it is docked.

Super-slim CD slot



Elegant design with super-slim CD slot

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favourite moments with family and friends.



Specifications

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/programme, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play, Shuffle Play
- Loader Type: Slot
- Cradle playback mode: Fast forward and reverse, Next and Previous track, Play and Pause, Charging iPhone, Charging iPod, Charging iPad

Sound

- Output Power: 30 W RMS total power
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Sound System: Stereo

Loudspeakers

- Main Speaker: 3" woofer, Bass Reflex Speaker System

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo
- Auto digital tuning
- Station presets: 20
- DAB: Band III, Info display, Menu, Smart Scan
- RDS: Programme Type, Radio Text, Station Name
- Tuner Enhancements: Auto Store

Connectivity

- Other connections: FM fixed pigtail antenna
- Audio Connections: 3.5 mm stereo line in -MP3 link

Convenience

- Alarms: Sleep timer, Radio Alarm, CD Alarm, iPod Alarm
- Clock: On main display

- Display Type: LCD
- Backlight colour: Blue
- Backlight

Accessories

- Included accessories: World Wide Warranty leaflet, 3.5 mm stereo line-in cable, Warranty certificate
- Quick start guide: 6 languages
- User Manual: Danish/Norwegian, English, French, German, Italian

Dimensions

- Set dimensions (W x H x D): 389.5 x 140 x 200.5 mm
- Packaging dimensions (W x H x D): 462 x 275 x 200 mm
- Weight incl. Packaging: 4.1 kg

Power

- Power supply: 50 Hz, 100-240 VAC, 50/60 Hz

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with colour display, iPod 1G, iPod 5th Generation, iPod classic, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod touch, iPod touch 2nd Gen 8/16/32 GB, iPod nano 6th generation

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPad compatibility

- Compatible with: iPad



Issue date 2013-05-31

Version: 1.0.4

12 NC: 8670 000 78815
EAN: 87 12581 61052 4

© 2013 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Music with Digital Rights Management not supported.