



Philips
docking speaker

for iPod/iPhone
Battery/AC powered



DS3020



Sound that fits your home

Obsessed with sound

On your desk or anywhere else, this dashing docking speaker delivers crystal-clear sound that fills your personal space. Synchronise your iPhone/iPod with your PC. Enjoy the option of AC or battery power for maximum flexibility.

Crystal clear sound

- DBB to preserve low tones for deep bass at any volume level
- Neodymium speakers for pure balanced sound
- Shielding technology to block mobile phone interference

Elegant and compact

- Compact design for any space, any lifestyle
- 360-degree design for gorgeous look from any angle

Advanced versatility

- PC synchronisation with your iPod/iPhone
- Battery or AC power option for music enjoyment anywhere
- Dock any iPod/iPhone, even in its case
- AUX-in for easy connection to almost any electronic device
- Free DockStudio app for Internet radio and other cool features

PHILIPS

Docking speaker
for iPod/iPhone Battery/AC powered

Specifications

iPhone compatibility

- Compatible with: iPhone, iPhone 3G, iPhone 3GS, iPhone 4

iPod compatibility

- Compatible with: iPod, iPod classic, iPod mini, iPod nano, iPod nano 1st Generation, iPod nano 2nd Generation, iPod nano 3rd Generation, iPod nano 4th Generation, iPod nano 5th Generation, iPod nano 6th generation, iPod touch, iPod touch 2nd Generation, iPod touch 2nd Gen 8/16/32 GB, iPod with colour display, iPod 5th Generation

iPod/iPhone App

- App name: DockStudio
- Free download from App store
- Compatibility: iPhone OS 3.0
- Playback: Album/track navigation, Playback controls
- Sound settings: DBB, DSC-Flat, Pop, Rock, Jazz, Classic
- Clock: Analogue display, Digital display
- Alarm: Multiple alarms, Sleep timer, Wake up to music, Wake up to nature sounds, Wake up to photos

Audio Playback

- Cradle playback mode: Charging iPhone



Sound

- Output power (RMS): 10 W
- Sound System: Stereo
- Volume Control: Volume Control up/down
- Sound Enhancement: Dynamic Bass Boost

Connectivity

- PC Link: USB 2.0
- Aux in

Loudspeakers

- Neodymium magnet system

Power

- Power supply: 100-240 VAC, 50/60 Hz, Battery
- Battery type: AA/LR6 Alkaline
- Number of batteries: 4
- Operating time on battery: 8 hr

Dimensions

- Master carton weight: 3.03 kg
- Product dimensions (WxDxH): 210 x 150 x 135
- Weight incl. Packaging: 1.33 kg
- Master carton dimensions: 300 x 240 x 145 mm
- Master carton quantity: 2
- Weight: 0.96 kg

Accessories

- Cables: 3.5 mm AUX-in
- USB cable: White

DS3020/05

Highlights

Dynamic Bass Boost (DBB)



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Neodymium speakers

Neodymium is the best material for producing a strong magnetic field for greater sensitivity in a voice coil, better bass response and a pure balanced sound quality.

PC synchronisation

Dock it, play it, sync it and charge it! Dig in to your favourite music on your iPod or iPhone while it charges and synchronises with your PC via USB — and enjoy superb sound quality together with thoroughly unbeatable convenience. Let the great tunes go on and on — without ever running out of power.



Issue date 2014-03-19

Version: 5.0.4

12 NC: 8670 000 72731
EAN: 87 12581 58477 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com