

Installation Guide

CED230/55









- 1 Illumination switch
- 2 To the +12V car battery which is energized at all time
- 3 Motor/electric antenna relay control lead. Amplifier relay control lead
- (4) Ground
- (5) Ignition key +12V DC when ON/ACC
- 6 Antenna

- 7 Subwoofer Out
- 8 Aux-In
- 9 Parking switch cable
- 10 Reverse driving cable
- (11) Video-In
- (12) Camera-In
- (13) Video-out 1 and 2
- (14) Rear line-out
- (15) Front line-out

Connect


These instructions are for a typical installation. However, if your car has different requirements, make the corresponding adjustment. If you have any questions regarding installation kits, consult your Philips car audio dealer.





Caution


- \bullet This unit is designed for negative ground (earth) 12 V DC operation only.
- Always install this unit in the car dashboard. Other locations can be dangerous as the rear of the unit heats up during
- To avoid short-circuit: before you connect, ensure that the ignition is off.
- Ensure that you connect the yellow and red power supply leads after all other leads are connected.
 Ensure that all loose leads are insulated with electrical tape.
- Ensure that the leads do not get caught under screws orin parts that will move (e.g. seat rail).
 Ensure that all ground (earth) leads are run to a common ground (earth) point.
 Use only the supplied mounting hardware for a safe and secure installation.
- Improper fuses can cause damage or fire. When you need to change the fuse, consult a professional.


Mount














Note on the power supply lead (yellow)

• When you connect other devices to this apparatus, ensure that the rating of the car circuit is higher than the total fuse value of all the connected devices.

Notes on speaker connection

- Never connect speaker wires to the metal body or chassis of the car.
 Never connect speaker wires with stripes to one another.



Caution

Make sure that all bare wires are insulated with electrical tape.



Note

• As different cars have different requirements, you might need to connect CED229 differently from the user manual's instructions. In that case, consult a professional mechanic to connect.

Connect parking brake cable and reverse driving cable to a rear view backup camera



Note

· Check your local driving regulations on whether it is legally required to install the rear view backup camera. These connections require a professional mechanic to install.

This car audio video system allows you to connect to the rear view backup camera. You can view the things that happens behind your car in the display, especially you are driving a big vehicle. This helps protecting your bumper and anything it might

• For proper operation of the DVD player, the chassis must be mounted within 20 degree horizontal. Ensure that the unit is mounted within this limitar



- Keep the connection of the car battery if there is an on-board drive or navigation computer. Otherwise, the
- computer may lost its memory.


 To avoid short circuit, ensure the bare wires do not touch each other and disconnect the negative terminal of the car battery.



Quick start guide













- Risk of explosion! Keep batteries away from heat, sunshine or fire. Never discard batteriesin fire.
 Risk of decreased battery life! Never mix different brands or types of batteries.
 Risk of product damage! When the remote control is not used for long periods, remove the batteries.
 Perchlorate Material special handling may apply. See www.dtsc.ca.gov/hazardouswaste/percholorate.















Turn on: Press OK/MUTE ① to turn on. Turn off: Press and hold the same button for 3 seconds to turn off.








CED230/55








Mute volume: Press OK/MUTE \odot on the unit or $\sqrt[4]{8}$ of the remote control to mute the sound.











Insert USB device:

- Slide down the USB socket cover.
 Then, insert the USB device into the USB socket.











- Insert SD/SDHC card or CD:

 1. Press to open the front panel.

 2. Insert the SD/SDHC card into the card slot, or CD into the disc slot.

 3. Flip and close the front panel.







