

Philips
DVD Micro Theatre

DivX

MCD296



Enjoy great movie experience

with DivX playback

You're in touch with the latest and the coolest - now get a load of the hot 2-in-1 Micro Hi-Fi with DVD, WMA-CD and MP3-CD playback! Relax to your favourite movies and music. Home entertainment will never be the same again!

Enrich your movie experience

- Play DVD, DivX®, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Dolby Digital for ultimate movie experience

Enrich your sound experience

- Loudness for bass and treble enhancement
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic bass
- 2x15W RMS/2x30W music power

Start the day your way

- Wake-Up and Sleep Timer
- Digital tuning with 40 preset stations for extra convenience

Refined in sound and look

- Motorised CD loader for convenience access
- Elegant wood-finished speakers

PHILIPS
sense and simplicity

Specifications

Sound

- **Output Power:** 2x15 watts RMS / 30 watts music power
- **Sound Enhancement:** Digital Sound Control 4 modes, Dynamic Bass Boost, Loudness
- **Sound System:** Dolby Digital

Loudspeakers

- **Main Speaker:** 2 way, 4" woofer, Bass Reflex Speaker System, Speaker grilles detachable

Video Playback

- **Playback Media:** DivX, DVD+RW, DVD-Video, Picture CD, Video CD/SVCD
- **Disc Playback Modes:** A-B Repeat, Angle, Zoom, Slow Motion, Parental control, PBC
- **DVD Region:** 2

Audio Playback

- **Cassette Deck Technology:** Mechanical
- **Cassette Playback Modes:** Electronic Speed Control
- **Playback Media:** CD, CD-R, CD-RW, MP3-CD, WMA-CD
- **Disc Playback Modes:** 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- **Loader Type:** Tray, Motorised

Audio Recording

- **Recording Media:** Tape
- **Tape Recording Enhancement:** CD Synchro Start Recording, Automatic Recording Level, One-Touch Recording

Tuner/Reception/Transmission

- **Tuner Bands:** FM Stereo, MW
- Auto digital tuning
- **Station presets:** 40

- **Tuner Enhancements:** Auto Store
- **RDS:** RDS Clock Set, Station Name, Radio Text

Connectivity

- **Aux in:** 3.5mm
- **Other connections:** MW Antenna, FM Antenna, Line out, Digital coaxial out, Subwoofer out
- **Video Output - Analogue:** Composite CVBS (yellow cinch), S-Video (on Hosiden)
- **Headphone:** 3.5 mm

Convenience

- **Alarms:** Sleep timer, CD Alarm, Radio Alarm
- **Clock:** On main display
- **Display Type:** LCD
- **Eco Power Standby:** 1 watt
- **OSD Languages:** Dutch, English, French, German, Italian, Portuguese, Spanish, Swedish, Turkish

Accessories

- **Included Accessories:** FM/MW Antenna, Composite video cable (Y), Guarantee booklet, Quick Use Guide
- **Remote control:** 40-key with Lithium batteries
- **IFU / User Manual:** English

Dimensions

- **Set dimensions (W x H x D):** 152 x 228 x 273 mm
- **Main speaker dimensions (W x H x D):** 140 x 228 x 212 mm
- **Packaging dimensions (W x H x D):** 345 x 275 x 442 mm
- **Weight incl. Packaging:** 7.8 kg

Power

- **Power supply:** 220-240V, 50Hz

Product highlights

Loudness for bass and treble

In the sound spectrum, high and low frequencies are relatively less audible to human ears - especially at low volumes. By activating the Loudness feature, the bass and treble will be amplified so you can savour a more balanced sound perception overall.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Dolby Digital

Because Dolby Digital, the world's leading digital multi-channel audio standards, make use of the way the human ear naturally processes sound, you experience superb quality surround sound audio with realistic spatial cues.

