



Philips
Mini Hi-Fi System

FWM600D

Enjoy MP3-CD music in rich sound

with USB Direct

Experience uninterrupted enjoyment of your CD/MP3/WMA songs for up to 10 hours on the FWM197. Extend your music pleasure by listening to your tunes at home from your portable player - with USB Direct and MP3 player-in.

Enrich your sound experience

- 120 W RMS total output power
- 2-Way Bass Reflex Speaker System for powerful sound
- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings
- Digital Sound Control for optimised music style settings

Continuous enjoyment of your favourite music

- USB Direct for MP3/WMA music playback
- 10 hours of MP3-CD music
- MP3 Link for portable music playback
- MW/FM digital tuning with presets
- Stereo cassette deck

PHILIPS

Highlights

120 W RMS

This system has a 120 W RMS total output power. RMS refers to Root Mean Square, which is a typical measurement of audio power, or rather, the electrical power transferred from an audio amplifier to a loudspeaker, which is measured in watts. The amount of electrical power delivered to the loudspeaker and its sensitivity determines the sound power that is generated. The higher the wattage, the better the sound power emitted by the speaker.

2-Way Bass Reflex System

2-Way Bass Reflex Speaker System for powerful sound

Stereo cassette deck

Stereo cassette deck

USB Direct

With the USB Direct mode, simply plug in your USB device to the USB port on your Philips device and your digital music will be played directly from the Philips device.

MP3 Link

The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

10 hours of MP3-CD music

MP3 stands for "MPEG 1 Audio layer-3". MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the standard audio compression format used on the Internet, allowing quick and easy audio file transfer.

Dynamic Bass Boost

Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Optimal, Jazz, Techno and Rock controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Specifications

Sound

- Output power (RMS): 120 W
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control

Loudspeakers

- Main Speaker: 2" tweeter, 2-way, Bass Reflex Speaker System, 5.25" woofer
- Number of Loudspeakers: 2

Audio Playback

- Number of Discs: 1
- Loader Type: Tray
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- USB Direct Modes: Fast Reverse/Fast Forward, Play/Pause, Previous/Next, Programme Play, Repeat, Stop, Shuffle
- Disc Playback Modes: Repeat/one/disc/programme, Shuffle Play, Fast Forward/Reverse, Next/Previous Track Search, Repeat Play
- Programmable Tracks: 20
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Automatic Stop

Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro-Start Recording

Tuner/Reception/Transmission

- Tuner Bands: FM Stereo, MW
- Auto digital tuning
- Auto store
- Number of Pre-set Channels: 40

Convenience

- Alarms: CD Alarm, USB alarm, Sleep timer
- Clock: On main display
- Display Type: LCD
- Eco Power Standby: 1 watt

Connectivity

- Aux in: 3.5 mm stereo
- USB: USB host
- Audio Connections: RCA Aux in

Accessories

- Included accessories: Remote Control, Guarantee booklet, Quick Use Guide
- User Manual: 16 Languages

Dimensions

- Set dimensions (W x H x D): 220 x 292 x 285 mm
- Packaging dimensions (W x H x D): 730 x 348 x 275 mm
- Weight incl. Packaging: 11.2 kg

Power

- Power supply: 200-240 V, 50 Hz
- Standby power consumption: < 2 W



Issue date 2014-04-21

Version: 1.0.5

12 NC: 8670 000 74967
EAN: 87 12581 59692 7

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com