



Philips  
DVD player

DVP3126X

## Simply plays it all

With 5.1 channel audio output

Does size matter? Ever heard of less is more? Introducing the best value DVD player. No complications! Just a simple set that plays practically any disc format, including your digital photos with absolutely no compromise to picture quality.

### **Bring audio and video to life**

- 12-bit/108MHz video processing for sharp and natural images
- 192kHz/24 bit audio DAC enhances analogue sound input
- 5.1 channel audio output for surround sound
- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality

### **Play all your movies and music**

- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW
- Plays MP3, WMA and JPEG digital camera photos

### **Fits any space, any lifestyle**

- Ultra-slim design that fits anywhere

# PHILIPS

# Specifications

## Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

## Sound

- D/A converter: 24 bit, 192 kHz
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Distortion and Noise (1kHz): 65 dB
- Crosstalk (1kHz): 70 dB
- Dynamic Range (1kHz): 80 dB
- Sound System: Dolby Digital

## Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2
- Video disc playback system: PAL, NTSC

## Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, WMA-CD, CD-R/RW, Audio CD
- MP3 bit rates: 32 - 320 kbps
- Compression format: PCM, MP3, Dolby Digital, WMA

## Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-

- R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom

## Connectivity

- Rear Connections: Composite video (CVBS) output, Digital coaxial out, ComponentVideo out
- Progressive, Analog audio Multi-channel out

## Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English, Polish, Russian

## Power

- Power consumption: < 10 W
- Standby power consumption: < 0.8 W
- Power supply: 230V, 50Hz

## Accessories

- Included accessories: Audio/Video cable, World Wide Warranty leaflet, Remote Control, 2 x AAA Batteries, User Manual

## Dimensions

- Set dimensions (W x H x D): 360 x 37 x 209 mm
- Packaging dimensions (W x H x D): 415 x 82 x 282 mm

# Highlights

## 192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

## 5.1 channel audio output

5.1 channel audio output for surround sound

## Plays it all

Play MP3s, WMA and JPEGs, and experience the convenience of sharing media files on your TV or home theater system - in the comfort of your living room.

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



12-bit  
Video DAC



Issue date 2014-02-10

Version: 1.0.3

12 NC: 8670 000 31297  
EAN: 87 12581 34395 8

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)