

Philips
Portable CD Player

EXP3373



Enjoy MP3 music in your own way

The eXp3373 lets you listen to MP3/WMA music on the move as well as enjoy great audio output via the integrated speakers of the convenient docking station once you are home. The docking station also charges the player for ultra convenience.

Your complete MP3-CD experience

- Plays MP3 and WMA digital audio
- Play CD, CD-R and CD-RW discs
- ID3 Tag Support for track information during CD playback

Sound Station for easy docking

- Integrate charging, amplifying and audio output in one system
- PDA type connector with visible LED for easy docking

Jogproof

- 200-second Magic ESP™

Enhanced bass performance

- Digital Dynamic Bass Boost for optimized bass at any volume

PHILIPS

Specifications

Sound

- Acoustic Feedback
- D/A converter: 1-bit
- Frequency response: 20 - 20 000 Hz
- Output Power: 2 x 5mW RMS(earphone)
- Output power (RMS): 2x1.5 W(Sound Station)
- Signal to noise ratio: > 85dB
- Sound Enhancement: Digital Dynamic Bass Boost
- Total Sound Power (RMS): 3 W
- Volume Control: digital

Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA
- Disc Playback Modes: 50-Track Programmable, Fast Forward/Backward, Hold, Next/Previous Album Search, Next/Previous Track Search, Repeat one/album/all, Resume Playback from stop, Shuffle album/all
- Electronic Skip Protection(CD): 45 seconds
- File systems supported: ISO-9660, Joliet, UDF
- ID3-tag support
- Magic ESP (MP3-CD): 100 seconds
- MP3 bit rates: 32 - 320 kbps
- WMA bit rates: 32 - 192 kbps

Connectivity

- DC in: 4.0 mm, 6.5V(Sound Station)
- Headphone: 3.5 mm
- Line-out: 3.5 mm

Convenience

- Display Type: LCD
- Indications: album name, album number, artis name, battery status, Cd functions, DBB, ESP, file name, sound titles, time, track



Accessories

- AC/DC Adaptor: AY3195(1.2A)
- Batteries: AY3363(Ni-MH rechargeable)
- CD-ROM: AY4484(Musicmatch)
- Docking Station: 2x1.5w output Sound Station
- Headphones: SBC HE225(with volumn control)
- Included accessories: User Manual

Dimensions

- Ebox dimensions (W x H x D): 0 x 0 x 0 mm
- Housing: Heat Resistant Body
- Master carton dimensions: 342 x 293 x 270 mm
- Master carton weight: 4 kg
- Master carton quantity: 2
- Packaging dimensions (W x H x D): 258 x 269 x 165 mm
- Packaging type: D-box
- Primary component dimensions (W x H x D): 0 x 0 x 0 mm
- Primary component width: 0 mm
- Primary component weight: 0 kg
- Product dimension (WxDxH) inch: 137.5x137.5x23.3mm(CD Player)
- Product weight: 0 kg

Power

- Battery Playing Time CD: 10h(2xAA alkaline batteries)
- Battery Playing Time MP3-CD: 20h(2xAA alkaline batteries)
- Battery Playing time (WMA): 20h(2xAA alkaline batteries)
- Battery type: AA, AAA, LR03, LR6, UM3, UM4
- Kind of Battery: Rechargeable
- Rechargeable

Highlights

Plays MP3 & WMA digital audio

Plays MP3 and WMA digital audio

Play CDs, CD-R and CD-RW

Philips is known for making products which are compatible with many discs available in the market. This audio system lets you enjoy music from CD, CD-R and CD-RW. CD-RW (CD-Rewritable Compatible) means that your audio system can play both CD-Recordable (CD-R) and CD-Rewritable (CD-RW) discs. CD-R discs are recordable once and can be played on any audio CD player while CD-RW discs can be recorded and rewritten multiple times and can only be played back on compatible audio CD players.

ID3 Tag Support

Players with ID3 Tag Support have an LCD screen that displays a text readout of the artist name and the title of the track currently being played so you can easily identify songs on your player. They show both numerical and text information in an easy-to-read format allowing you to conveniently view the artist name and track title. ID3 Tag Support lets you quickly and easily identify and navigate through the large number of files on your MP3-CD or WMA-CD.

Integrated sound system

Integrate charging, amplifying and audio output in one system

PDA type connector

PDA type connector with visible LED for easy docking

200-second Magic ESP™

Magic Electronic Skip Protection™ is a convenient feature that ensures skip-free music even when your MP3-CD player is subjected to knocks and jolts while you are jogging or on the move. Devices with Magic Electronic Skip Protection™ have an intelligent electronic buffer that can store different digital music formats such as MP3, WMA and CDDA. The buffer adjusts both its contents and laser spin speeds automatically to guarantee uninterrupted music listening.

Digital Dynamic Bass Boost

Digital Dynamic Bass Boost is an intelligent bass booster that delivers maximum bass enhancement at high volumes without sound distortion and at low volumes without compromising on bottom-end bass frequencies. Technologically advanced electronics constantly monitor volume and bass levels, precisely calibrating both to prevent sound distortion, thus producing optimized bass. Digital Dynamic Bass Boost enables the enjoyment of superb bass performance - regardless of the chosen volume level.



Issue date 2014-02-05

Version: 4.0.5

12 NC: 9073 101 01197
EAN: 87 10895 81026 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com