

Philips  
DVD Mini Hi-Fi System



FWD832

## Ideal TV pal with superb sound

Enjoy music with virtual surround sound

The sleek and stunning FWD832 delivers amazing sound to enrich your entertainment experience in the comfort of your home. Expand and boost your sound stage with its powerful 3-way speaker system and Incredible Surround™.

### Enrich your movie experience

- Dolby Digital for ultimate movie experience
- Progressive Scan component video for optimized image quality

### Enrich your sound experience

- 2500W PMPO / 150W RMS total power
- 3-way Speaker System with MAX bass port
- Incredible Surround™ for enhanced audio enjoyment
- Digital Sound Control for optimized music style settings
- Virtual Ambience Control provides simulated sound settings

### Continuous enjoyment of your favorite music

- Play DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) & Picture CD
- Digital tuning with 40 preset stations for extra convenience
- Stereo cassette deck
- Karaoke for endless singing entertainment

**PHILIPS**  
sense and simplicity

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## 3-way spk sys with MAX port

3-way Speaker System with MAX bass port

## Incredible Surround™

Incredible Surround is an audio technology from Philips that dramatically magnifies the sound field to immerse you in the audio. Using state-of-the-art electronic phase shifting, Incredible Surround mixes sounds from left and right in such a way that it expands the virtual distance between the two speakers. This wider spread greatly enhances the stereo effect and creates a more natural sound dimension. Incredible Surround allows you to experience total surround with greater depth and width of sound, without the use of additional speakers.

## Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Virtual Ambience Control

Virtual Ambience Control (VAC) creates a virtual sound environment which digitally mimics the acoustic characteristic of special rooms or environments such as concert halls, the cinema, arcades, discos, etc. By realistically recreating the sound ambience of these different settings, VAC will dramatically enhance your enjoyment of your favorite music.

## Play DVD, MP3, WMA, Picture CD

The Philips player is compatible with most DVD and CD discs available in the market. DVD, (S)VCD, MP3-CD, WMA-CD, CD(RW) and Picture CD - all of them can play on the player. SVCD stands for "Super VideoCD".

The quality of a SVCD is much better than a VCD, especially much more sharpen picture than a VCD because of the higher resolution. CD(RW) is a shorthand term for a CD drive that can accept the common rewritable CD format.

## 40-preset digital tuning

Digital radio offers you additional music options to your music collection on your Philips audio system. Simply tune into the station that you want to preset, press and hold the preset button to memorize the frequency. With preset radio stations that can be stored, you can quickly access your favorite radio station without having to manually tune the frequencies each time.

## Stereo cassette deck

Stereo cassette deck

## Karaoke

The Karaoke feature on your DVD player provides endless entertainment and maximum audio and singing enjoyment. You can enhance your performance by adding an 'echo' effect to your voice. The key controls allows you to choose the optimal key for your personal vocal range.



# Specifications

## Sound

- Output Power: 150W rms / 2500W PMPO
- Sound Enhancement: Dynamic Bass Boost 3 steps, Virtual Ambience Control, Digital Sound Control, Incredible Surround
- Sound System: Dolby Digital

## Loudspeakers

- Main Speaker: 3 way, 2" tweeter, 2 x 5.25" woofer, Bass Reflex Speaker System
- Number of Loudspeakers: 2

## Video Playback

- Loader Type: Motorised
- Number of Discs: 1
- Playback Media: DVD, Video CD, Picture CD, SVCD, DVD+R/+RW, DVD-R/-RW
- Disc Playback Modes: A-B Repeat, Disc Menu, OSD, Fast Forward, Fast Backward, Slow Forward, Slow Backward, Search forward/reverse, Resume Playback from Stop, Repeat, Chapter repeat, Angle, Zoom
- Video Enhancement: Progressive Scan

## Still Picture Playback

- Playback Media: Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Slideshow, Flip photos, Rotate, Zoom

## Audio Playback

- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: Next/Previous Track Search, Repeat/Shuffle/Program
- Programmable Tracks: 16
- Number of decks: 1
- Cassette Deck Technology: Mechanical
- Cassette Playback Modes: Fast Wind/Rewind, Automatic Stop

## Audio Recording

- Recording Media: Tape
- Tape Recording Enhancement: CD Synchro Start Recording

## Tuner/Reception/Transmission

- Auto digital tuning
- Tuner Bands: FM Stereo, MW
- Tuner Enhancements: Auto Store, Easy Set (Plug & Play)
- Station presets: 40

## Connectivity

- Headphone: 3.5 mm
- Microphone: Dual Microphone sockets
- Other connections: ComponentVideo out Progressive, Composite video (CVBS) out, S-Video out, Subwoofer out, Digital output (cinch), Line out, FM Antenna, MW Antenna
- Aux in: Line in

## Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer, Tape alarm
- Display Type: FTD
- Karaoke: Echo control, Key control, MIC volume
- Clock: On main display
- OSD Languages: English, Portuguese, Russian, Spanish

## Accessories

- Included accessories: AC Power Cord, Quick start guide, Video Cable, YPbPr component video cable, FM/MW Antenna
- Standard Package Includes: International Guarantee
- Remote control: 40-key with battery
- User Manual: English

## Dimensions

- Set dimensions (W x H x D): 177 x 292 x 341 mm
- Main speaker dimensions (W x H x D): 165 x 410 x 285 mm
- Packaging dimensions (W x H x D): 568 x 423 x 458 mm
- Weight incl. Packaging: 13 kg

## Power

- Power supply: 100-240VAC, 50/60Hz



Issue date 2011-03-30

Version: 1.2.6

12 NC: 9073 100 13546  
EAN: 87 10895 98372 3

© 2011 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)