

Philips NULL Wireless Headphone

32mm drivers/closed-back On-ear Soft ear cushions

TAKH402PK

Shine like a star

Get them ready to rock with the funky on-ear headphones that light up. These tough, wireless headphones are volume-limited to 85 dB. An LED panel in the ear cup lets kids brighten their style with colorful lights.

20 hours play time. Safe sound. Bright lights.

- 20 hours play time. No wires, no tangles
- 32 mm acoustic drivers. Clear sound
- LED light panels in the ear cups
- Volume limited to 85 dB

Plays where you play

- Flexible, adjustable headband. Twist it, bend it
- Smart pairing. Automatically find Bluetooth devices
- User friendly button control

Ready for you

- · Comfort ear and headband cushions. Perfect for young ears
- Customizable ear cups. Stickers included
- Flat-folding and compact-folding design. Easy storage



Specifications

Accessories

- · Quick start guide
- USB cable

Connectivity

- Microphone: Built-in microphone
- Bluetooth profiles: A2DP, AVRCP, HFP, HSP
- Bluetooth version: 5.0
- Maximum range: Up to 10m m

Convenience

- Volume control
- · Call Management: Call on Hold, Answer/End Call, Reject Call

Design

· Color: Pink

Power

- Battery type: Li-Polymer
- · Standby time: 800 hrs
- · Talk time: 20 hrs
- Music play time: 20 hr

Sound

- Acoustic system: Closed
- Magnet type: NdFeB
- Frequency response: 20 20 000 Hz
- · Impedance: 32 Ohm
- Speaker diameter: 32mm

- Maximum power input: 10 mW
- Diaphragm: PET
- Sensitivity: 95dB
- Type: dynamic

Packaging dimensions

- · Number of products included: 1
- Packaging dimensions (W x H x D): 17 x 20 x 4.5 cm
- Gross weight: 0.215 kg
- Nett weight: 0.123 kg
- Tare weight: 0.092 kg
- EAN: 48 95229 10094 7

Outer Carton

- Number of consumer packagings: 3
- Outer carton (L x W x H): 23.5 x 19.6 x 16.1 cm
- Gross weight: 0.796 kg
- Nett weight: 0.369 kg
- Tare weight: 0.427 kg
 GTIN: 1 48 95229 10094 4

Dimensions

- Headband arc length: 300 360 mm
- Product dimensions (WxDxH): 3.5 x 15 x 16 cm
- Product weight: 0.114 kg

UPC

• UPC: 8 40063 20039 5

AKH402PK/00

Highlights

20 hours play time.

From trips away to a week's worth of screen timekids will love these wireless on-ear headphones. They get 20 hours play time from a single charge: enough to entertain for a few days or more.

32 mm acoustic drivers.

Specially designed to protect young ears, these headphones boast 32 mm acoustic drivers that have been limited to 85 dB. You can relax, knowing your kids are enjoying their tunes, videos, and games safely.

Comfort ear & headband cushion

Soft ear-cup cushions and a soft headband cushion keep the kids comfortable-whether they're listening to music or watching their favorite YouTubers.

Customizable ear cups.

There's even a set of stickers included, so children can decorate these headphones however they like!

Compact-folding design. These wireless on-ear children's headphones feature a clever design that folds in two directions. You can fold them flat, perfect for storing in a bedroom drawer. Or you can fold them flat and inwards, creating a compact bundle that fits into coat pockets and bags.

Flexible, adjustable headband

The strong, flexible headband adjusts easily and is tough enough to withstand being thrown in a backpack or dropped on the floor. It can even be twisted hard without breaking. Whatever the kids get up to, their headphones will stay in one piece.

LED light panels

The ear cups feature LED panels that light up for an extra dash of funky style. There are four variations to choose from: red lights, green lights, blue lights, or a mix of all three! Simply press the button on the ear cup to cycle through the light options.

Smart pairing. One long press of the multi-function button gets these wireless Bluetooth headphones ready to pair. Once they're paired, the headphones remember the last device they were paired with.

User friendly button control

User friendly button makes it easy for kids to take a call, skip a track, or pause what they're listening to. All without touching their smartphone. Volume buttons on the base of the ear cup are easy to reach, as is the LED light button.

Volume limited to 85 dB

You can relax, knowing your kids are enjoying their tunes, videos, and games safely.



Issue date 2021-09-26

© 2021 Koninklijke Philips N.V. All Rights reserved.

Version: 4.3.3

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

12 NC: 8670 001 61516 EAN: 48 95229 10094 7

www.philips.com