



Philips  
Surge protector

Home electronics

4 outlets

SPN3040B



## Eliminate Cable Clutter

Designed to perform and protect, this surge protector features advanced technologies to keep equipment safe from electrical surges. Power Blocker® circuitry automatically shuts down power to your system to protect against subsequent surges.

### Pure Protection

- 900 Joules
- Power Blocker
- €100,000 equipment warranty

### Built-in convenience

- 4 outlets with protection
- 4 m power cord
- Built-in cord management

### Simplicity

- Integrated automatic child safety outlets
- Worry-free protection indicators

**PHILIPS**  
sense and simplicity

# Specifications

## Packaging dimensions

- Packaging dimensions (W x H x D):  
14 x 38 x 5.5 cm
- Net weight: 0.811 kg
- Gross weight: 0.911 kg
- Tare weight: 0.1 kg
- EAN: 87 12581 51887 5
- Number of products included: 1
- Packaging type: Box

## Outer Carton

- Outer carton (L x W x H): 38 x 18.5 x 16 cm
- Net weight: 2.433 kg
- Gross weight: 3.013 kg
- Tare weight: 0.580 kg
- EAN: 87 12581 54565 9
- Number of consumer packages: 3

# Highlights

## 900 Joules

Prevent thousands of pounds of damage to your electronic devices.

## Power Blocker

Automatically shuts down power to the connected devices.

## €100,000 equipment warranty

Protects your connected equipment for the life of the product.

## 4 outlets with protection

Protects against surges/spikes through the AC lines by suppressing surge energy. The excess energy is clamped by the MOV when the unit is subjected to a surge event.

## 4 m power cord

Provides power to the unit which can be 4 m from the AC outlet.

## Cord Management

A cord management device that allows the cable/cords to be routed in the same direction for a more organised appearance

## automatic child safety sockets

Helps keep children safe from accidental shock.

## Protection indicators

LED lights let you know if your surge protector is functioning properly.



Issue date 2013-03-03

Version: 1.2.6

12 NC: 8670 000 58714  
EAN: 87 12581 51887 5

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)