



Philips
Cube micro sound system

CD, MP3-CD, USB, FM

24W max
24W max

MCM1055B



Relax with great music

Obsessed with sound

Enjoy your favorite CDs and portable music just the way you like it. The Philips cube micro music system plays CDs and more, it also features USB Direct for portable music playback. The compact design fits any space, any lifestyle.

Enrich your sound experience

- Bass Reflex Speaker System delivers a powerful, deeper bass
- Digital Sound Control for optimized music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 24W RMS maximum power

Enjoy your music from multiple sources

- Enjoy MP3/WMA music directly from your portable USB drives
- Play MP3/WMA-CD, CD and CD-RW
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience

PHILIPS

Highlights

Dynamic Bass Boost



Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high - at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound

Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media players. Besides the benefit of enjoying your favorite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player to the audio system.

USB Direct for MP3/WMA music



Simply plug in your device to the USB port on your Philips Hi-Fi system. Your digital music will be played directly from the device. Now you can share your favorite moments with family and friends.

Specifications

Audio playback

- Playback media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc playback modes: repeat/shuffle/program
- USB Direct playback modes: fast backward/fast forward, play/pause, previous/next, program play, repeat, shuffle, stop

Sound

- Sound enhancement: Dynamic Bass Boost, digital sound control
- Volume control: up/down
- Maximum output power (RMS): 24W

Loudspeakers

- Speaker drivers: 3" woofer

Tuner/Reception/Transmission

- Tuner bands: FM stereo
- Station presets: 20
- Antenna: FM fixed pigtail antenna
- Tuner enhancement: auto digital tuning, auto scan

Connectivity

- Audio/Video output: Headphone (3.5mm)
- MP3 Link: 3.5mm stereo line in

Convenience

- Alarms: USB alarm, CD alarm, radio alarm
- Loader type: top
- Clock: on main display, sleep timer
- Display type: LCD display
- Backlight color: white

Accessories

- Cables/Connection: MP3 Link cable
- Remote control
- Others: Quick start guide
- User Manual: multi-languages
- Warranty: World Wide Guarantee booklet

Dimensions

- Gross weight: 3.4 kg
- Main speaker dimensions (W x D): 140 x 198 mm
- Main speaker height: 143 mm
- Packaging depth: 248 mm
- Main unit depth: 210 mm
- Main unit height: 143 mm
- Packaging height: 200 mm
- Packaging width: 550 mm
- Main unit width: 140 mm
- Net weight: (main unit) 0.91 kg, (speaker box) 2 x 0.72 kg

Power

- Power supply: 110-240V, 50/60Hz



Issue date 2014-06-12

Version: 1.0.4

12 NC: 8670 000 90522
EAN: 87 12581 64579 3

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com