

Philips  
5 DVD/CD Changer  
Home Theater



HTS5510C



## See, hear, experience everything

This stylish and compact full digital home entertainment system plays practically any disc in high quality Dolby or DTS surround sound. So relax and fully immerse yourself in movies and music in your own personal environment.

### Great audio and video performance

- Progressive Scan component video for optimized image quality
- Superwoofer with 20.3cm/8" driver for a powerful performance
- Dynamic Bass Boost for deep and dramatic sound

### Play it all

- Movies: DVD, DVD+R/RW, (S)VCD, DivX, MPEG4
- Music: CD, CD-R/RW and MP3-CD
- Picture CD (JPEG) with music (MP3) playback

### Ultimate convenience

- Full length tower speakers for more impressive sound
- Fast 5 disc changer for endless music

# PHILIPS

# Highlights

## Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

## Superwoofer 20.3 cm/8" driver

Superwoofer with 20.3 cm (8") driver meets the demands of the most discerning listener through providing more power and volume, thereby maximizing the bass experience.

## Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level.

To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Multi-format Movies-DivX, MP4

Multi-format playability allows you to play most disc formats for maximum compatibility and viewing pleasure.

## Full length tower speakers

Full length tower speakers for more impressive sound



# Specifications

## Picture/Display

- Aspect ratio: 4:3, 16:9
- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan, Video upsampling

## Sound

- D/A converter: 24bit, 192kHz
- Sound System: Dolby Prologic II, DTS, Dolby Digital, Stereo
- Sound Enhancement: Night Mode, Dynamic Bass Boost
- Equalizer settings: Action, Classic, Concert, Digital, Drama, Jazz, Rock, Sci-Fi
- Output power (RMS): 6x150W
- Total Sound Power (RMS): 900 W
- Frequency response: 30-20000 Hz
- Signal to noise ratio: > 65dB

## Video Playback

- Playback Media: DVD+RW, DVD+R, DVD-RW (Video mode), DVD-R, DVD-Video, Video CD/SVCD, CD-R/CD-RW, MP3-CD, MPEG4, Picture CD, DivX
- Number of Discs: 5

## Audio Playback

- MP3 bit rates: 32-256 kbps and VBR

## Still Picture Playback

- Playback Media: Picture CD, DVD+R/+RW, CD-R/RW
- Picture Compression Format: JPEG
- Slide show: with music (MP3)

## Tuner/Reception/Transmission

- Antenna: AM Antenna, FM Antenna
- Auto digital tuning
- Auto store
- Number of Preset Channels: 20

## Connectivity

- Other connections: AM Antenna, AUX in, Digital coaxial in, Line out, S-Video out, TV in (audio, cinch), ComponentVideo out Progressive, Composite video (CVBS) out, FM Antenna

## Power

- Power supply: 100-240VAC, 50/60Hz
- Standby power consumption: < 0.5W
- Power consumption: 380 W

## Loudspeakers

- Satellite Speaker: Magnetically shielded front, 2 way
- Satellite speaker freq range: 120-20000 Hz
- Satellite speaker drivers: 1" conical dome tweeter, 3" full range woofer
- Center Speaker: Magnetically shielded, 3 way
- Center freq range: 120-20000 Hz
- Center speaker drivers: 1" conical dome tweeter, 2 x 3" full range woofers
- Subwoofer type: Active
- Subwoofer freq range: 30-120 Hz
- Subwoofer driver: 8" high efficiency woofer
- Subwoofer impedance: 6 ohm
- Center speaker impedance: 6 ohm
- Satellite speaker impedance: 6 ohm

## Accessories

- Included accessories: Video Cable, Audio Cable, Interconnect cable, AM/FM Antenna, Remote Control, Batteries for remote control, User Manual, Warranty certificate, Quick Use Guide
- Remote control: 3139 258 70091

## Dimensions

- Weight incl. Packaging: 35 kg
- Subwoofer dimensions (W x H x D): 236 x 360 x 470 mm
- Subwoofer Weight: 10.76 kg
- Set dimensions (W x H x D): 435 x 74.4 x 441 mm
- Set weight: 5.6 kg
- Center speaker dimensions (W x H x D): 246 x 93 x 68 mm
- Center Speaker Weight: 1.34 kg
- Packaging dimensions (W x H x D): 1216 x 517 x 576 mm
- Surround Speaker dimensions (H x D): 1078 x 255 (diameter) mm
- Surround speaker Weight: 2.75 kg



Issue date 2014-02-11

Version: 3.0.7

12 NC: 9073 100 12887  
EAN: 87 10895 90519 0

© 2014 Koninklijke Philips N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips N.V.  
or their respective owners.

[www.philips.com](http://www.philips.com)