

Philips
5.1 Home theater

420W RMS power
DVD playback

HTS3277



Spectacular surround sound with superb clarity

Just like in the movies

High quality surround sound and HDMI 1080p upscaling delivered by this system provides superb home entertainment. Playback from USB drives, portable media players and just about any type of disc lets you enjoy movies and music effortlessly.

Bring audio and video to life

- DTS, Dolby Digital and Pro Logic II surround sound
- Advanced Class D Amplifier for compact, powerful sound
- HDMI 1080p upscales to high definition for sharper pictures

Connect and enjoy multiple sources

- Hi-Speed USB 2.0 Link plays video/music from USB flash drive
- Multiple digital inputs for quality sound from other sources

Easy to set up and use

- EasyLink to control all HDMI CEC devices via a single remote

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays WMV, DivX, WMA, MP3 and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW, DVD+R DL

PHILIPS

Highlights

DTS, DolbyDigital, ProLogic II

A built-in DTS and Dolby Digital decoder eliminates the need for an external decoder by processing all six channels of audio information to provide a surround sound experience and an astoundingly natural sense of ambience and dynamic realism. Dolby Pro Logic II provides five channels of surround processing from any stereo source.

Advanced Class D Amplifier

Advanced Class D Amplifier for compact, powerful sound

HDMI 1080p

HDMI 1080p upscaling delivers images that are crystal clear. Movies in standard definition can now be enjoyed in true high definition resolution - ensuring more details and more true-to-life pictures. Progressive Scan (represented by "p" in "1080p") eliminates the line structure prevalent on TV screens, again ensuring relentlessly sharp images. To top it off, HDMI makes a direct digital connection that can carry uncompressed digital HD video as well as digital multichannel audio, without conversions to analog - delivering perfect

picture and sound quality, completely free from noise.

Hi-Speed USB 2.0 Link

The Universal Serial Bus or USB is a protocol standard that is conveniently used to link PCs, peripherals and consumer electronic equipment. Hi-Speed USB devices have a data transfer rate of up to 480 Mbps - up from the 12 Mbps in original USB ones. With Hi-Speed USB 2.0 Link, all you have to do is plug in your USB device, select the movie, music or photo and play away.

EasyLink

EasyLink lets you control multiple devices like DVD players, Blu-ray players, TV's etc. with one remote. It uses HDMI CEC industry-standard protocol to share functionality between devices through the HDMI cable. With one touch of a button, you can operate all your connected HDMI CEC enabled equipment simultaneously. Functions like standby and play can now be carried out with absolute ease.

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Plays it all

Play virtually any media format you want - whether they be WMV, DivX, MP3s or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

Plays it all

Play virtually any disc you want - whether they be CDs, (S)VCDs, DVDs, DVD+R, DVD-R, DVD+RW, DVD-RW or DVD+R DL. Experience unbeatable flexibility and the convenience of playing all your discs on the one device.



Specifications

Picture/Display

- D/A converter: 12bit, 108MHz
- Picture enhancement: Progressive scan, High Def (720p, 1080i, 1080p), Video Upscaling(720p, 1080i/p)

Sound

- Total Power (RMS): 420 W
- Output power (RMS): 4x55W, 2x100W
- D/A converter: 24 bit, 192 kHz
- Frequency response: 40-20000 Hz
- Signal to noise ratio: > 60 dB
- Sound System: Dolby Digital, Dolby Prologic II, DTS, Stereo
- Equalizer settings: Action, Classic, Concert, Drama, Gaming, Lounge, Rock, Sports
- Sound Enhancement: Class "D" Digital Amplifier, Night Mode

Video Playback

- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra, WMV, MPEG4
- Playback Media: DVD-Video, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD, CD-R/CD-RW
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: MP3, WMA
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- MP3 bit rates: 32-256 kbps and VBR

Still Picture Playback

- Picture Compression Format: JPEG
- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, USB flash drive
- Picture Enhancement: Rotate, Zoom, Slideshow with music playback

Tuner/Reception/Transmission

- Tuner Bands: FM
- RDS: Station Name

Connectivity

- Rear Connections: AUX in, FM Antenna, Scart, Easy-Fit Speaker Connectors, Composite video (CVBS) output, HDMI output, Digital coaxial in, Digital optical out
- Front / Side connections: Hi-Speed USB, MP3 Line-in

Power

- Power supply: 50Hz, 230V
- Standby power consumption: < 1 W
- Power consumption: 80 W

Loudspeakers

- Satellite speaker drivers: 3" full range woofer
- Satellite speaker impedance: 8 ohm

- Satellite speaker freq range: 150-20000 Hz
- Center speaker drivers: 3" full range woofer
- Center speaker impedance: 4 ohm
- Center freq range: 150-20000 Hz
- Subwoofer driver: 6.5" high efficiency woofer
- Subwoofer type: Passive
- Subwoofer impedance: 4 ohm
- Subwoofer freq range: 40-150 Hz

Accessories

- Included accessories: Remote Control, 2 x AAA Batteries, FM antenna, User Manual, Quick start guide, World Wide Warranty leaflet, Scart Cable

Dimensions

- Set dimensions (W x H x D): 360 x 57 x 331 mm
- Set weight: 2.87 kg
- Center speaker dimensions (W x H x D): 244 x 100 x 74 mm
- Center Speaker Weight: 0.791 kg
- Subwoofer dimensions (W x H x D): 163 x 363 x 369 mm
- Subwoofer Weight: 4.703 kg
- Packaging dimensions (W x H x D): 962 x 440 x 409 mm
- Weight incl. Packaging: 21 kg
- Front Speaker Depth: 71 mm
- Front Speaker Height: 203 mm
- Front Speaker Weight: 0.54 kg
- Front Speaker Width: 103 mm
- Rear Speaker Depth: 264 mm
- Rear Speaker Height: 1199 mm
- Rear Speaker Weight: 3.376 kg
- Rear Speaker Width: 262 mm

Outer Carton

- EAN: 87 12581 50561 5
- Gross weight: 20.8 kg
- Outer carton (L x W x H): 96.2 x 40.9 x 44 cm
- Nett weight: 17.007 kg
- Number of consumer packagings: 1
- Tare weight: 3.793 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 96.2 x 44 x 40.9 cm
- EAN: 87 12581 50561 5
- Gross weight: 20.8 kg
- Nett weight: 17.007 kg
- Number of products included: 1
- Packaging type: Carton
- Tare weight: 3.793 kg
- Type of shelf placement: Laying

Product dimensions

- Cable length: 0 cm
- Product dimensions (W x H x D): 36 x 5.5 x 33.3 cm
- Weight: 3.06 kg



Issue date 2014-02-12

Version: 2.0.6

12 NC: 8670 000 56484
EAN: 87 12581 50561 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com