

# PHILIPS



CD Soundmachine

Bluetooth

50 W

Dynamic light



PX840T

## Enjoy powerful music wirelessly wherever you go with Bluetooth

The Philips PX840T portable sound system plays music effortlessly from your favourite sources — Bluetooth, USB, CD and FM/MW radio. The built in, dynamic lighting system and 50W power output let you have the ultimate listening experience.

### Easy to use

- 20-track CD programmable
- CD Shuffle/Repeat for personalised music enjoyment
- 20 preset tuning stations
- Pump up the party with dynamic light

### Enjoy your music from different sources

- Play MP3-CD, CD and CD-R/RW
- FM/MW (AM) stereo tuner
- Audio-in for easy portable music playback
- USB Direct for MP3 music playback
- Stream music wirelessly via Bluetooth™ from your smartphone

### Powerful sound you can hear and feel

- Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimised music style settings
- 50W RMS maximum output power

# Highlights

## Stream music via Bluetooth™



Bluetooth is a short-range wireless communication technology that is both robust and energy efficient. The technology allows easy wireless connection to an iPod/iPhone/iPad or other Bluetooth devices, such as smartphones, tablets or even laptops. So you can easily and wirelessly enjoy your favourite music, video or game on this speaker.

## USB Direct for MP3 music

USB Direct for MP3 music playback

## Play MP3-CD, CD and CD-R/RW



MP3 stands for "MPEG 1 Audio layer-7.6 cm (3)". .MP3 is a revolutionary compression technology by which large digital music files can be made up to 10 times smaller without radically degrading their audio quality. MP3 has become the

standard audio compression format used on the world wide web, allowing quick and easy audio file transfer.

## FM/MW (AM) stereo tuner

FM/MW (AM) stereo tuner

## Light up the party



Get the party pumping with dynamic lighting to illuminate your music. Set the night alight with two cool dynamic lighting effects that shine directly from the speakers. Turn the lights on or off with the flip of a switch, without missing a beat. Light up the party however you like, from ambient chill-out lighting to exciting dance club effects, set the tone and mood at the same time!

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume

settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



# Specifications

## Sound

**Output Power:** Total 50W max.  
**Volume control:** rotary (digital)  
**Sound system:** stereo

## Loudspeakers

**No. of built-in speakers:** 2 full range + 2 passive radiators

## Connectivity

**USB:** USB host  
**Bluetooth profiles:** A2DP, AVRCP  
**Audio in (3.5 mm)**

## Audio playback

**Disc playback modes:** fast forward/reverse, next/previous album search, next/previous track search, repeat/shuffle/programme  
**Playback media:** CD, CD-R, CD-RW, MP3-CD  
**USB playback mode:** fast forward/reverse,

next/previous album search, next/previous track search, repeat/shuffle/programme  
**Bluetooth**

## Tuner/Reception/Transmission

**Antenna:** FM antenna  
**Tuner bands:** FM, MW (AM)

## Convenience

**Backlight**  
**Backlight colour:** Amber  
**Loader type:** top  
**Display type:** LCD display

## Power

**Battery type:** D size (LR20)  
**Battery voltage:** 1.5 V  
**Mains power:** AC 100V–240V  
**Power supply:** AC or battery input  
**Number of batteries:** 8

## Accessories

**Others:** User Manual  
**Cables/Connection:** AC-DC adapter  
**Warranty:** Warranty leaflet

## Dimensions

**Weight incl. Packaging:** 4.8 kg  
**Product dimensions (WxDxH):** 523 x 223 x 210 (7.2" x 3.2" x 3.4") mm  
**Packaging dimensions (WxDxH):** 560 x 265 x 265 mm (9.2" x 3.7" x 3.8")  
**Product weight:** 3.8 kg

