



Philips Streamium
Network Music Player

Streamium



NP3700



Stream music from PC/MAC and Internet - wirelessly

Obsessed with sound

FullSound™ rejuvenates compressed music, making MP3s leap to life. You'll get the most out of your entire music collection - through wireless streaming of the Philips NP3700/12. Plus, a full-color touch screen hands you effortless control.

Unlimited listening pleasure - wirelessly

- Tune in and explore thousands of Internet radio stations
- Wireless stream music and photos from your PC/MAC
- Stream and enjoy over 10 million great songs from Napster*

Easy navigation and control

- View album art in full color
- Full color touch screen for easy navigation

Ready to connect

- Works with home broadband connection and Wi-Fi router
- Optional iPod/iPhone dock for convenient music playback
- Turn your Smartphone into a remote for Philips AV products

Quality sound performance

- FullSound enriches your music with fuller bass and clarity
- 10W RMS total output power

PHILIPS

Highlights

Wireless stream music & photos



Your PC/ MAC is filled with music that you can now conveniently stream onto your Philips audio device – without messy cables. Share your favorite songs with others at a party, or simply enjoy them at the comfort of your home. Do the same for your photo collections, and view them at leisure while you listen to music. Unlock your PC/ MAC treasures with the convenience of wireless streaming.

Full color touch screen



Touch screen control allows you to control your device by simply pressing on-screen buttons rather than physical buttons on the device. Simply power up the device and the touch screen user interface will show up on the LCD display with all the control options for the device. Touch screen control combines LCD display technology with pressure sensors and a powerful digital micro processor. When you press on a specific area of the screen with your finger, the relevant signal is sent to the processor and the command is immediately executed.

MyRemote app



The Philips MyRemote app lets you use your iPhone, iPod Touch or Android Smartphone as a remote to control your Philips networked AV products. The app automatically recognizes your Philips Blu-ray player, Home theater or Streamium audio system connected to your home Wi-Fi network, and gives you instant control over the devices from anywhere in your home. And if you have more than one Philips networked AV product, the app will allow you to switch between them and control each one independently. This free app is created exclusively by Philips.

Napster online music library*



Get all the music you ever want with Napster - an online music service that offers you over 10 million tracks from 790,000 artists, 980,000 albums and all genres. Access to Napster is made effortless with the Philips micro system, thanks to the icon-based LCD display panel, and gives you all the music you want - quickly and easily. With just a few clicks, Napster's vast library is freed from your PC or MAC, and streamed wirelessly for you to enjoy on the Philips system. Change the way you listen to music now.

Internet radio stations



Streamium comes with thousands of Internet radio stations. Now you can stay abreast of all kind of music worldwide. Connect your Streamium to the Internet and listen to your favorite online programs without having to turn on your PC/MAC.

Optional iPod/iPhone dock



Your choices just got wider. Not only can you play music from CDs, and via MP3 Link, AUX-in, and wireless PC/MAC streaming, you can now play from your iPod and iPhone. Simply dock your iPod or iPhone, switch to docking mode, and select the songs you want to hear using the remote control. The docking cradle, available as an optional accessory, unleashes your personal collection onto a superb sound system.

Album art

Bring life to your listening experience with full colour pictures of album covers. Embedded in music files are album art graphics which display automatically during song selection and playback. Your music simply comes to life with album art.

Specifications

Sound

- Equalizer settings: Neutral
- Sound Enhancement: Treble and Bass Control
- Volume Control: up/down
- Music Power: 2x5W
- Type: FullSound, Incredible Sound

Loudspeakers

- Built-in speakers: 2
- Loudspeaker types: Integrated

Audio Playback

- Compression format: MP3, WMA, non DRM AAC (m4A), eAAC+, FLAC, Ogg Vorbis
- Sample frequencies: 8-48 kHz (MP3)
- PC Link playback mode: MP3 streaming via network, Wi-Fi wireless connection
- ID3-tag support
- Internet Radio
- MP3 bit rates: 8-320kbps and VBR

Connectivity

- Headphone: 3.5 mm
- Wireless connection: Wireless LAN (802.11n), Wireless LAN(802.11g), Wireless LAN(802.11b)
- Wireless Universal Plug & Play: UPnP client
- LAN wired: Ethernet (RJ 45) 1x
- Encryption / security: WEP 128 bit, WEP 64 bit, WPA, WPS-PBC, WPS-PIN, WPA2
- Audio Connections: 3.5mm stereo line in -MP3 link
- Connector pin: DCK3060 iPod/iPhone dock
- Other connections: Ethernet

Still Picture Playback

- On-device display: Streaming from PC
- Picture Compression Format: JPEG

Convenience

- Display Type: Touch screen LCD
- Backlight
- Backlight color: White
- On-Screen Display languages: English, Dutch, French, German, Italian, Spanish, Portuguese, Swedish, Russian, Simplified Chinese, Traditional Chinese
- Eco Power Standby: 1 watt
- Headphone jack
- Signal strength indication
- Clock: On main display, Internet time
- Alarms: Buzzer Alarm, Sleep timer, Music Alarm (UPnP)
- Display Enhancements: Brightness Control, Touch screen control
- Indications: DIM mode

Accessories

- Included accessories: World Wide Warranty leaflet
- Remote control: 1-way Remote
- Batteries: 2x AAA
- Quick start guide: English, French, German, Spanish, Italian, Dutch, Norwegian, Swedish, Finnish, Portuguese, Danish, Russian, Polish
- User Manual: English, French, German, Spanish, Italian, Dutch, Norwegian, Swedish, Finnish, Portuguese, Danish, Russian, Polish (in CD)
- CD-ROM: CD-ROM with TwonkyMedia and user manuals
- Warranty Card: Warranty Card
- AC/DC Adaptor: 110-240V

Dimensions

- Product dimensions (WxDxH): 291 x 148 x 152 mm
- Set weight: 1.48 kg



Issue date 2022-06-03

Version: 2.1.7

12 NC: 8670 000 63723
EAN: 87 12581 54744 8

© 2022 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Napster is available only in Germany and the United Kingdom.