



Philips
DVD player with USB

DivX Ultra

DVP5160



Straight from USB to TV

with DivX Ultra

The DVP5160 provides flawless, true-to-life picture quality. Designed to play virtually any type of disc, it delivers an outstanding and immersive movie and music entertainment experience.

Bring audio and video to life

- 12-bit/108MHz video processing for sharp and natural images
- Smart Sound optimizes audio settings
- 192kHz/24 bit audio DAC enhances analogue sound input
- High quality outputs for analog and digital audio
- Progressive Scan component video for optimized image quality

Play all your movies and music

- DivX Ultra Certified for enhanced playback of DivX videos
- Plays DivX, MP3, WMA and JPEG digital camera photos
- Plays CD, (S)VCD, DVD, DVD+R/RW, DVD-R/RW

Easy to use

- USB Direct plays photos and music from USB flash drives

Fits any space, any lifestyle

- Ultra-slim design that fits anywhere

PHILIPS

Highlights

DivX Ultra Certified

With DivX support, you are able to enjoy DivX encoded videos in the comfort of your living room. The DivX media format is an MPEG4-based video compression technology that enables you to save large files like movies, trailers and music videos on media like CD-R/RW, and DVD recordable discs. DivX Ultra combines DivX playback with great features like integrated subtitles, multiple audio languages, multiple tracks and menus into one convenient file format.

Plays it all

Play virtually any media format you want - whether they be DivX, MP3s, WMA or JPEGs. Experience the unbeatable convenience of great playability, and the luxury of sharing media files on your TV or home theater system - in the comfort of your living room.

192kHz/24 bit audio DAC

192kHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original

analogue sound wave form, giving a much richer audio reproduction.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.



Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Smart Picture, Video upsampling

Sound

- D/A converter: 24 bit, 192 kHz
- Signal to noise ratio: 100
- Distortion and Noise (1kHz): 85 dB
- Crosstalk (1kHz): 100 dB
- Dynamic Range (1kHz): 90 dB
- Sound System: Dolby Digital
- Frequency response: 30-20000 Hz

Video Playback

- Playback Media: CD, CD-R/CD-RW, Video CD/SVCD, DVD, DivX, DVD+R/+RW, DVD-R/-RW, DVD-Video
- Compression formats: MPEG1, MPEG2, DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, DivX Ultra
- Video disc playback system: PAL, NTSC

Audio Playback

- Playback Media: CD, MP3-CD, MP3-DVD, CD-R/RW, WMA-CD, Audio CD
- Compression format: Dolby Digital, MP3, PCM, WMA
- MP3 bit rates: 32 - 320 kbps

Still Picture Playback

- Playback Media: DVD+R/+RW, DVD-R/-RW, CD-R/RW, Picture CD, Kodak Picture CD
- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Zoom,

Slideshow with MP3 playback

Multimedia Applications

- Multimedia connections: USB memory class device
- Playback Formats: DivX, MP3, JPEG Still pictures

Connectivity

- Rear Connections: Analog audio Left/Right out, Composite video (CVBS) output, Digital coaxial out, Component Video out Progressive, Scart

Convenience

- Child Protection: Parental Control, Child Lock
- On-Screen Display languages: Danish, Dutch, English, Finnish, French, German, Italian, Norwegian, Portuguese, Spanish, Swedish, Turkish, Polish

Accessories

- Included accessories: 2 x AAA Batteries, Quick start guide, Remote Control, World Wide Warranty leaflet, User Manual

Dimensions

- Set dimensions (W x H x D): 435 x 38 x 209 mm
- Packaging dimensions (W x H x D): 490 x 82 x 296 mm
- Set weight: 1.6 kg
- Weight incl. Packaging: 2.8 kg

Power

- Power supply: 50Hz, 230V
- Power consumption: < 10 W
- Standby power consumption: < 0.8 W



Issue date 2017-04-04

Version: 2.1.13

12 NC: 8670 000 27654
EAN: 87 12581 31966 3

© 2017 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com