



Philips  
Micro music system

• 40 W



MCM3050



# Sound that fits your home

Obsessed with sound

Take pleasure in music from multiple sources — from MP3-CDs and radio, to portable devices via USB Direct and MP3 Link. This Philips micro-music system also features wOOx technology for deep bass and comes with stylish wall-mount options.

## Enrich your sound experience

- wOOx™ loudspeaker Technology for deep and powerful bass
- Digital Sound Control for optimised music style settings
- Dynamic Bass Boost for deep and dramatic sound
- 40 W RMS total output power

## Enjoy your music from multiple sources

- Play MP3/WMA-CD, CD and CD-RW
- USB Direct for MP3/WMA music playback
- MP3 Link for portable music playback
- Digital tuning with preset stations for extra convenience
- Radio Data System for station information and data services

## Design that blends into your interior

- Wall-mountable option for flexible placement
- Motorised sliding front door adding style and elegance

# PHILIPS

# Highlights

## wOOx™ Technology



wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

## Digital Sound Control



Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classical controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.

## Dynamic Bass Boost



Dynamic Bass Boost maximises your music enjoyment by emphasising the bass content of the music throughout the range of volume settings - from low to high – at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

## USB Direct



With the USB Direct mode, you can simply select the music on a USB device and play back all your content. All you have to do is plug in your USB device to play back music or export content from the device.

## MP3 Link



The MP3 link connectivity allows direct playback of MP3 content from portable media

players. Besides the benefit of enjoying your favourite music in the superior sound quality delivered by the audio system, the MP3 link is also extremely convenient as all you have to do is to plug your portable MP3 player into the audio system.

## Radio Data System (RDS)

The Radio Data System (RDS) lets you tune into radio stations without having to remember the frequencies. In standard mode, RDS displays the station name instead of the transmission frequency, facilitating quick and easy tuning. RDS also allows stations to send text messages such as news and station information directly to the radio display. Commonly used in Europe, RDS text is sent out on the same frequency the radio station broadcasts on. You can choose either the basic RDS display (station name) or subscribe to additional text-based services.

## Wall-mountable



The perfect combination of a slim and versatile design, your Philips audio system is cleverly designed to blend into your living space. The base of the audio system is a stand so the system can sit securely and nicely on any shelf or cabinet. When wall mounted you have all the same flexibility of the freestanding stand.



# Specifications

## Sound

- Output power: 2 x 20 W RMS
- Sound enhancement: wOOx™ Technology, digital sound control, Dynamic Bass Boost
- Volume control: up/down

## Loudspeakers

- No. of built-in speakers: 2
- Speaker drivers: 3" woofer

## Audio playback

- Disc playback modes: fast forward/reverse, next/previous track search, repeat/shuffle/programme
- Playback media: CD, CD-R/RW, MP3-CD, USB flash drive, WMA-CD
- USB Direct playback modes: fast reverse/fast forward, play/pause, previous/next, repeat, shuffle, stop
- Others: ID3-tag support

## Tuner/Reception/Transmission

- Tuner bands: FM mono, FM stereo
- Station presets: 20
- RDS: programme type, radio text, RDS clock set, station name
- Antenna: FM antenna (75 ohm)
- Tuner enhancement: auto digital tuning, auto scan, Easy set (plug and play)

## Connectivity

- Headphones: 3.5 mm
- MP3 Link: 3.5 mm stereo line in
- USB: USB host

## Convenience

- Alarms: CD Alarm, Radio Alarm, USB alarm
- Clock: On main display, sleep timer
- Display Type: VFD display
- Loader type: front, motorised

## Accessories

- Included accessories: 3.5 mm stereo line-in cable, AC Power Cord, FM antenna, Quick Use Guide, Screws for wall mounting x 2
- Remote control: 31-key remote
- User Manual: 16 languages

## Dimensions

- Set dimensions (W x H x D): 500 x 217 x 98 mm
- Packaging width: 585 mm
- Packaging height: 281 mm
- Packaging depth: 180 mm
- Gross weight: 4.3 kg
- Net weight: 3.4 kg

## Power

- Power supply: 220-240 V, 50 Hz



Issue date 2013-05-10

Version: 1.1.3

12 NC: 8670 000 78233  
EAN: 87 12581 60780 7

© 2013 Koninklijke Philips Electronics N.V.  
All Rights reserved.

Specifications are subject to change without notice.  
Trademarks are the property of Koninklijke Philips  
Electronics N.V. or their respective owners.

[www.philips.com](http://www.philips.com)