



Micro Music System

- Bluetooth®
- CD, MP3-CD, USB, FM
- USB port for charging
- 18W

TAM3205/12

Ready for the sounds you love

Hear more from every podcast and playlist you stream. Rediscover your CD collection or tune in to the radio. This classic looking micro system sounds great in smaller rooms, and you can connect other sources via USB or audio-in.

Benefits

Great sound for your music

- Bass-reflex loudspeakers. Richer low tones
- Classic design
- Digital Sound Control. Choose a preset sound style
- 3" woofer. 18 W maximum output power

From CD classics to streaming

- All your music
- CD player. Digital FM radio with 10 presets. Audio-in
- USB port. Connect a legacy source or charge a mobile

Features

All your music

This stylish micro system lets you stream playlists and more via Bluetooth, play CDs and listen to FM radio. The digital radio tuner with 10 presets delivers clear reception, and the CD player can read MP3 CDs and recorded CDs.

- Bluetooth. Stream music, podcasts, and more

Fill the room with tunes

- At home in your home
- AC-powered. Remote control
- Main unit dimensions: 180x121x247 mm
- Speaker dimensions: 150x238x125 mm

Bass-reflex loudspeakers

Bookshelf-style loudspeakers give you clear sound and good bass from 3" woofers and bass-reflex ports. An 18 W maximum output brings decent sound to smaller spaces. Perfect for a home office or bedroom.

PHILIPS

Classic design

The two-tone central unit and speaker cabinets recall the design of hi-fi separates. The textured volume-control dial adds a satisfying analog feel to operation. There are buttons on the front of the unit for playback and source selection.

Digital Sound Control

Hip-hop or choral, symphony or rock opera? Whatever you love, this micro system's Digital Sound Control function lets you enjoy it more. Pick from preset sound styles designed to bring out the best in your music.

Specifications

[field not found 'disclaimer_text']

Sound

Maximum output power (RMS)	18W
Sound enhancement	digital sound control bass reflex speaker system
Sound mode	Powerful Clear Bright Warm Balanced
Volume control	rotary
Frequency response	66-20000 Hz
Speaker impedance	6 ohm

Loudspeakers

Number of sound channels	2.0
Driver configuration	Full range
Number of full range drivers	2
Full range driver diameter	3"

Audio playback

Playback media	CD CD-R/RW MP3-CD USB flash drive
Disc playback modes	fast forward/backward next/previous track search repeat/shuffle/program
USB Direct playback modes	fast backward/fast forward play/pause previous/next repeat shuffle stop
Audio supported formats	MP3
Max sample rate	24-bit/44.1kHz

Tuner/Reception/Transmission

Tuner type	Digital
Tuner bands	FM mono FM stereo
Antenna	FM fixed pigtail antenna
Station presets	10 (FM)
Tuner enhancement	auto digital tuning auto scan Easy set (plug & play)
RDS	No

Connectivity

Bluetooth profiles	A2DP AVRCP Multipoint (Multipair) support
Bluetooth range	10M (free space)
Bluetooth version	4.2
USB	USB host

At home in your home

This AC-powered micro system looks great in any room. Bluetooth wireless range is 10 m, and you can charge a smart device via the USB port. An easy-to-use remote puts key functions at your fingertips.

USB charging	5V, 1A
Audio in	3.5mm
Smart Home	n.a.
DLNA Standard	n.a.

Convenience

Clock	On main display 24/12 hour display
Display type	LED display
Loader type	tray
Alarms	Yes, Buzzer, FM, CD
No. of alarms	1
Sleep timer	Yes
Remote Control	Yes

Design

System components	Main control unit Speakers
Wall mountable	No

Compatibility

Smartphone/tablet APP control	No
-------------------------------	----

Power

Power supply	100-240VAC, 50/60Hz
--------------	---------------------

Accessories

Included accessories	Remote Control (with battery) AC power cord FM antenna Quick start guide Warranty Leaflet
Power cord	Length 1.5 m

Dimensions

Main Unit (W x H x D)	180x121x247 mm
Main Unit Weight	1.6 kg
No. of speaker unit	2
Speaker Unit (W x H x D)	150x238x125 mm
Speaker Weight (per Unit)	0.96 kg
Set (W x H x D)	500x238x247 mm
Set Weight	3.59 kg

Packaging dimensions

Depth	18.5 cm
EAN	48 95229 10981 0
Gross weight	4.65 kg
Height	31.2 cm
Nett weight	3.59 kg
Tare weight	1.06 kg
Number of products included	1
Packaging type	Box
Width	57.7 cm

Type of shelf placement

Standing



data subject to change
2023, November 30

Version: 10.1.3
EAN: 4895229109810

© 2023 Koninklijke Philips N.V.
All rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com