

Philips
DVD player

DivX playback

DVP3040



Turn up your experience

With DivX playback

Your dream player with flawless, true-to-life picture quality and the ability to play virtually any disc! The Philips DVD player delivers your movies and music entertainment experience.

Fits everywhere, goes anywhere

- Compact design
- Ultra-slim design

Play it all

- Movies: DVD, DVD+R/RW, DVD-R/RW, (S)VCD, DivX
- Photos: Picture CD (JPEG)
- Music: CD, MP3-CD, CD-R/RW & Windows Media™ Audio

Great audio and video performance

- RGB on Scart single connection for high-quality video
- 192kHz/24 bit audio DAC enhances analogue sound input
- Progressive Scan component video for optimized image quality

PHILIPS

Highlights

Multi-format Movies with DivX

Multi-format playability allows you to play most disc formats for maximum disc compatibility and viewing pleasure.

RGB on Scart connectivity

RGB on Scart is a cable connection that provides easy connectivity for high quality video output.

Picture CD (JPEG)

Multi-format playability allows you to view images in the comfort of your living room and play most disc formats for maximum disc compatibility and viewing pleasure.

192kHz/24 bit audio DAC

192KHz sampling enables you to have an accurate representation of the original sound curves. Together with a 24-bit resolution, more information is captured from the original analogue sound wave form, giving a much richer audio reproduction.

Ultra-slim design

The attractive enclosure has a very low profile.

Progressive Scan

Progressive Scan doubles the vertical resolution of the image resulting in a noticeably

sharper picture. Instead of sending a field comprising the odd lines to the screen first, followed by the field with the even lines, both fields are written at one time. A full image is created instantaneously, using the maximum resolution. At such a speed, your eye perceives a sharper picture with no line structure.

Music: Windows Media™ Audio

Multi-format playability allows you to play most disc formats for maximum disc compatibility and listening pleasure.



Specifications

Picture/Display

- D/A converter: 12 bit, 108 MHz
- Picture enhancement: Progressive scan, Video upsampling

Sound

- Crosstalk (1kHz): 70 dB
- D/A converter: 24 bit, 192 kHz
- Distortion and Noise (1kHz): 65 dB
- Dynamic Range (1kHz): 80 dB
- Frequency response: 30-20000 Hz
- Signal to noise ratio: 90
- Sound System: Dolby Digital

Video Playback

- Compression formats: DivX 3.11, DivX 4.x, DivX 5.x, DivX 6.0, MPEG1, MPEG2
- Playback Media: CD, CD-R/CD-RW, DivX, DVD, DVD+R/+RW, DVD-R/-RW, Video CD/SVCD
- Video disc playback system: NTSC, PAL

Audio Playback

- Compression format: Dolby Digital, MP3, PCM, WMA
- Playback Media: CD, CD-R/RW, MP3-CD, MP3-DVD, WMA-CD
- MP3 bit rates: 32 - 256 kbps

Still Picture Playback

- Playback Media: CD-R/RW, DVD+R/+RW, DVD-

R/-RW, Kodak Picture CD, Picture CD

- Picture Compression Format: JPEG
- Picture Enhancement: Flip photos, Rotate, Slideshow, Zoom

Connectivity

- Rear Connections: Analog audio Left/Right out, ComponentVideo out Progressive, Composite video (CVBS) output, Digital coaxial out, Scart

Convenience

- Child Protection: Child Lock, Parental Control
- On-Screen Display languages: English

Accessories

- Included accessories: 2 x AAA Batteries, Quick start guide, Remote Control, User Manual, World Wide Warranty leaflet

Power

- Power consumption: < 10 W
- Power supply: 240V, 50Hz
- Standby power consumption: < 0.8 W

Dimensions

- Packaging dimensions (W x H x D): 415 x 82 x 320 mm
- Set dimensions (W x H x D): 360 x 37 x 235 mm



Issue date 2014-02-10

Version: 1.1.7

12 NC: 8670 000 24907
EAN: 87 10895 99807 9

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com