



Philips Prestigo
Universal remote control

PRESTIGO



SRU9600

See only the keys you need

Made to simplify controlling your equipment

Now you can finally put away all your remote controls and replace them with one beautiful controller. The SRU 9600 not only handles all the functions of your original remotes, it is also much easier and more convenient to use.

Single control solution for most devices & brands

- 8 in1 controller for all home entertainment equipment
- Extensive infrared code database for most devices & brands
- Convenient IR learning from another remote

Great convenience

- Shows only the keys you need on the touch-sensitive display
- Easy access to advanced commands via interactive LCD display
- LCD screen with backlighting for convenience in the dark
- Rotary cursor control for fast menu navigation
- Control multiple devices with a single touch

Quick and easy set-up

- Intelligent setup wizard means no PC needed for installation
- No manual needed for set up

PHILIPS
sense and simplicity

Highlights

8in1 remote control

The universal remote control allows you to program and operate up to 8 devices from almost any brand.

Universal IR code database

A universal IR code database refers to a library of infrared codes built-in to a particular remote. This feature allows a remote to control your equipment without needing to learn individual signals. Select the correct infrared code sets in the database for the devices you want to control, to enable control of virtually every audio/video system element on the market today – regardless of model or brand.

Learning functionality

Learning functionality refers to the process through which a remote control captures and stores infrared signals from other remotes for later use. When device codes are not included in the on-board database, they can always be learned from the original remote, simply by pointing to it.

Touch-sensitive display

Through the special inverted segmented display technology, only those keys are lit up that are needed to control a specific device. No need to look for the right buttons anymore.

Interactive LCD display

The interactive LCD is a 4-line dot matrix LCD display that guides you through the settings, as well as the different devices.

Backlight on screen

Backlighting is a feature that illuminates the LCD screen or keypad for use in the dark. The two most common types of backlighting include LED and electroluminescent (EL). Remotes backlit with LEDs are typically bright but uneven with a yellow or green color, while EL panels are smooth with blue, white or green shades.

Intuitive rotary cursor

A cursor incorporating a rotary wheel enables you to navigate through the setup menu and the device pages, in both clockwise and counter-clockwise directions.

One-touch convenience



One-touch control allows you to perform multiple commands with one press of a button via a macro. A macro combines a string of pre-programmed commands under one single button. Therefore, it simply takes one button press to execute a series of functions.

Setup wizard



The setup wizard provides a step by step guide that tailors the device to perfectly match your home entertainment system. By learning what equipment you have, and how it is interconnected, the device creates its own macros that allow full control of your home entertainment system.

Guided setup

Unlike other universal remote controls, where a 3-digit code needs to be input to identify a brand and device, this remote incorporates on-device step-by-step instructions to setup your equipment, regardless of brand.

Specifications

Convenience

- Supported devices: TV, VCR, DVD, SAT, CABLE, CD/MD, RECEIVER, AMP, TIVO, PC, TAPE, TV-DVD, TV-VCR, DVR
- Scrollwheel
- Backlight
- Backlight color: White
- On-Screen Display languages: English, French, German, Spanish

Infrared Capabilities

- Operating distance: 33 ft (10 m)
- Learning IR codes
- Transmitting LEDs: 2
- Number of brands in database: Over 1100
- Carrier frequency range: 30k - 100kHz + 455kHz

Power

- Battery saving manager: Auto switch on/off
- Battery type: AA / LR6 Alkaline
- Number of batteries: 3

Packaging Data

- 12NC: 908210005336
- EAN/UPC/GTIN: 6 09585 11138 7
- Gross weight: 0.35 kg
- Length: 330 mm
- Width: 162 mm
- Height: 42 mm

Inner Carton

- EAN/UPC/GTIN: 1 06 09585 11138 4
- Quantity: 2
- Gross weight: 0.775 kg
- Tare weight: 0.112 kg
- Length: 341 mm
- Width: 171 mm
- Height: 105 mm

Outer Carton

- EAN/UPC/GTIN: 2 06 09585 11138 1
- Quantity: 4
- Gross weight: 1.748 kg
- Tare weight: 0.183 kg
- Length: 354 mm
- Width: 184 mm
- Height: 230 mm

Inner Carton

- Gross weight: 1.697 lb
- Inner carton (L x W x H): 13.2 x 6.5 x 3.9 inch
- Nett weight: .802 lb
- Tare weight: .895 lb

Outer Carton

- Gross weight: 3.818 lb
- Outer carton (L x W x H): 13.6 x 7 x 8.8 inch
- Nett weight: 1.605 lb
- Tare weight: 2.213 lb

Packaging dimensions

- Packaging dimensions (W x H x D): 7.1 x 12.9 x 1.5 inch
- Gross weight: .711 lb
- Nett weight: .401 lb
- Tare weight: .31 lb



Issue date 2009-11-06

Version: 3.0.10

12 NC: 8670 000 32587
UPC: 6 09585 13965 7

© 2009 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com