

Philips
Digital PhotoFrame

20.3cm/8"

Multimedia
4:3 frame ratio

SPF4008



"...this is where he proposed!"

Showcase those unforgettable moments with this PhotoFrame. This frame is designed for maximum ease of use as well as eco-friendliness. Rest assure that while you are enjoying your photos, you made the right choice for the environment.

Top quality display for amazing viewing experience

- 4:3 aspect ratio for optimal distortion-free display
- imagen Pro for sharp, vibrant and natural skin colors
- Add new glow to old memories with RadiantColor

Simple intuitive operation and great convenience

- Automatic slideshow from USB or memory card
- Auto photo orientation to fit portrait or landscape modes

Environmentally friendly green design

- Eco-friendly PhotoFrame
- Auto on/off display at pre-set times for power saving



asimpleswitch.com

PHILIPS

Specifications

Picture/Display

- Viewing angle: @ C/R > 10, 120° (H) / 100° (V)
- Lifetime, to 50% brightness: 20000 hr
- Aspect ratio: 4:3
- Panel resolution: 800 x 600
- Brightness: 250 cd/m²
- Contrast ratio (typical): 300:1

Connectivity

- USB: USB 2.0 Host, USB 2.0 Slave

Storage Media

- Built-in memory (RAM): 512MB (for 500 HD photos)
- USB: USB flash drive
- Memory Card Types: Secure Digital (SD), Secure Digital (SDHC), Multimedia Card, xD card, Memory Stick, Memory Stick Pro, Memory Stick Duo (via adaptor), MS Pro Duo (via adaptor)

Convenience

- Photo format supported: JPEG photo, Up to 10MB JPEG files, Up to 20 Megapixels
- Video format supported: MotionJPEG
- Background Music supported: MP3
- Card Reader: Built-in (1x)
- Placement: Photo auto orientation, Landscape, Portrait
- Buttons and controls: 3 buttons, 4-way navigation key and enter, Power button
- Playback mode: Full screen browse, Slideshow, Thumbnail browse
- Album management: Create, Delete, Edit, Rename
- Photo edit: Copy, Delete, Rotate, Zoom & crop
- Slideshow setting: Random, Sequential, Transition effect, Collage (multiple pictures)
- Setup function: Slideshow, Clock display enable/disable, Event reminder with snooze
- Regulatory approvals: CE, GOST, Switzerland
- Other convenience: Kensington lock compatible

Accessories

- Included accessories: AC-DC Adapter, Quick start guide, User manual on CD-ROM
- User Manual: Arabic, Czech, Danish/Norwegian, Dutch, English, Finnish, French, German, Greek, Italian, Malay, Polish, Portuguese, Russian, Simplified Chinese, Spanish, Swedish, Traditional Chinese, Turkish

Dimensions

- Set dimensions with stand (W x H x D): 206.4 x 139.3 x 103 mm
- Weight: 0.345 kg
- Temperature range (operation): 0°C to 40°C
- Temperature range (storage): -20°C to 70°C

Power

- Power supply: 100-240VAC, 50/60Hz
- DC output Volt: 9 V
- Power mode supported: AC powered
- DC output Ampere: 1 A
- Power consumption: (System on) 5.6 W

Packaging dimensions

- Packaging dimensions (W x H x D): 25 x 21 x 9.5 cm
- Nett weight: 0.88 kg
- Gross weight: 1.13 kg
- Tare weight: 0.25 kg
- EAN: 87 12581 50377 2
- Number of products included: 1
- Packaging type: Carton

Outer Carton

- Outer carton (L x W x H): 26 x 20 x 21.9 cm
- Nett weight: 1.76 kg
- Gross weight: 2.54 kg
- Tare weight: 0.78 kg
- GTIN: 1 87 12581 50377 9
- Number of consumer packagings: 2



Highlights

imagen Pro for vibrant colors

The unique Philips imagen enhancement technology automatically analyzes your photos to correct color and adjust for optimal contrast. imagen Pro is a more advanced image enhancement which includes the 3 essential elements from imagen to have more color accuracy, color depth and smart contrast. On top of these, imagen Pro offers enhanced skin color, sharper images and flicker-free photo viewing which is very important for still pictures.

4:3 perfect frame ratio

Philips digital PhotoFrame ensures your photo to be displayed in 4:3 ratio for the best viewing experience.

RadiantColor

RadiantColor is an exclusive Philips technology for displaying smaller photos in the optimal 4:3 ratio by extending the color on the edges of a less-than-full-screen photo to the sides of the screen, eliminating black bars and aspect ratio distortion.

Automatic slideshow

Automatic slideshows start from any USB drive or memory card for all those moments you don't want to spend time copying photos to your PhotoFrame.

Auto orientation

Automatic landscape/portrait recognition employs a sensor that recognizes PhotoFrame orientation and displays each photo in its proper mode.

Eco-friendly Photoframe

Philips PhotoFrame are designed and produced according to our EcoDesign principles aimed at minimizing overall environmental impact, through lower power consumption, removal of hazardous substances, lower weight, more efficient packaging and better recyclability.

Auto on/off display

A timer turns PhotoFrame on and off at the hours you select, reducing energy consumption for the sake of our environment saving up to one third of your PhotoFrame energy costs.



Issue date 2014-02-10

Version: 2.1.10

12 NC: 8670 000 56062
EAN: 87 12581 50377 2

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com