



Philips
docking entertainment
system with wOOx™
Technology

Dock for iPod and GoGear



AJ300D

Start your day, your way!

Wake up to your favorite iPod tunes

Free your portable music at home. Dock your iPod or GoGear player into the compact Philips clock radio with powerful bass supported by 12W RMS power. Enjoy great sounds and choose to kick-start each day with music.

Rich and clear sound

- Play and charge your iPod and GoGear
- wOOx™ loudspeaker Technology for deep and powerful bass
- Aux-in connection for your portable MP3 music player

Start the day your way

- Wake up to your iPod or GoGear music
- Dual alarm time
- Digital tuning for station presets

Easy to use

- 5 one touch buttons for easy access to favorite radio tunes
- Single remote control for the system and iPod

PHILIPS

Highlights

wOOx™ Technology

wOOx technology is a revolutionary loudspeaker concept that allows you to hear and feel profoundly deep bass that is richer than any other audio system. Special speaker drivers work in harmony with the wOOx bass radiator, and precise tuning between the main driver and the tweeter ensures smooth transitions from low-mid to high frequencies. Dual suspension and a totally symmetrical

sandwich construction deliver low and precise base without noticeable distortion. wOOx produces exceptionally deep and dynamic bass by using the speaker box full volume to truly magnify the impact of the music.

Aux-in connection

Aux-in connection for your portable MP3 music player

Wake up to iPod/GoGear music

Wake up to your iPod or GoGear music

Digital tuning for presets

Digital tuning for station presets

5 one-touch radio presets

Access your favorite stations with simple one touch operation



Specifications

iPod compatibility

- Compatible with: iPod, iPod mini, iPod nano, iPod with color display, iPod 5th generation

GoGear compatibility

- Compatible with: HDD6330/ HDD6320/ HDD1850/ HDD1840/ HDD1835/ HDD1830/ HDD1820/ HDD1635/ HDD1630/ HDD1620/ HDD1420/ SA9100/ SA9200

Tuner/Reception/Transmission

- Tuner bands: FM
- Station presets: 5
- Antenna: FM antenna
- Tuner enhancement: auto digital tuning

Audio playback

- Docking playback modes: fast forward and backward, next and previous track, play and pause

Convenience

- Alarms: 24 hour alarm reset, buzzer alarm, dual alarm, radio alarm, repeat alarm (snooze)
- Display type: LCD display
- Backlight color: blue
- Clock: Digital, sleep timer
- Charging device: GoGear, iPod

Sound

- Sound system: stereo
- Volume control: up/down
- Output power: 2 x 6 W RMS

Loudspeakers

- No. of built-in speakers: 5
- Speaker drivers: Neodymium magnet system
- Loudspeaker enhancement: wOOx Bass Radiator

Connectivity

- MP3 Link: 3.5mm stereo line in

Power

- Adaptor type: 100 - 240V AC, 50/60Hz
- Power type: AC Input

Dimensions

- Gross weight: 1.94 kg
- Weight: 1.34 kg
- Main unit depth: 164 mm
- Packaging depth: 212 mm
- Main unit height: 191 mm
- Packaging height: 224 mm
- Main unit width: 161 mm
- Packaging width: 248 mm



Issue date 2014-02-06

Version: 2.1.8

12 NC: 8670 000 26955
UPC: 6 09585 12487 5

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com