



Philips
Cordless telephone

CD530IS

Welcome to the color world

The rich color screen brings the CD5 series to life by adding another dimension to making a call. Color not only facilitates navigation in the icon menu, but also adds more depth to associated features.

Colours that bring your phone to life

- Selectable wallpapers
- Icon-driven colour menu
- Great for gaming with the embedded games

Pure convenience

- Identify your friends by the ringtone
- Backlit display & keypad
- Keep in touch by SMS texting

Clear calls around the house

- Polyphonic ringtones for a more natural and realistic sound
- Speakerphone - Talk handsfree
- Virtually interference free

PHILIPS
sense and simplicity

Specifications

Picture/Display

- Backlight
- Backlight colour: White
- Display colours: 4096 colours
- Main Display Resolution: 98x67 pixel
- Main Display Technology: CSTN
- Main Display Type: Graphic

Sound

- Handset ringers: Instrumental, Polyphonic
- Volume Control: Volume Control up/down

Convenience

- Alarms: Alarm Clock
- Backlit keypad: Yes (Amber)
- Base Station keys: Paging key
- Battery charging indication
- Call Management: Call Waiting, Caller ID, Microphone mute
- Ease of Use: Graphical User Interface, Hands free mode, Keypad Lock, Menu Control
- Embedded Games: 1
- Function: Baby Call, Babysit function
- Multi base capability: 1
- Multi handset capability: Up to five handsets
- Personalisation/Customization: Wallpaper
- Signal strength indication
- VIP group with own melody: Yes, 3 groups

Dimensions

- Base dimensions: 118 x 114 x 61 mm
- Handset dimensions: 153 x 50 x 29 mm

Power

- Battery capacity: 1 hr 2100mAh AA
- Battery type: AAA
- Battery Type: NiMH
- Kind of Battery: Rechargeable
- Mains power: AC 220-240V - 50Hz
- Number of batteries: 2
- Standby time: Up to 150 hours
- Talk time: up to 12 hours

Network Features

- Antenna: Integrated on base, Integrated on handset
- Compatible: GAP
- Dialling: Tone, Pulse
- Messaging: SMS (Short Message Service)

Operator Requirements

- Name and Caller ID
- Caller ID on call waiting

Memory Capacity

- Call log entries: 50
- Phonebook: 50 names and numbers
- Number of SMS Boxes: 10
- SMS storage capacity: 50

Product highlights

Icon-driven colour menu

All functions are grouped into several menu items that are symbolised by a coloured icon. This facilitates navigation and use of the phone.

Selectable wallpapers

An illustration is worth more than a thousand words. Scroll through the selection of images integrated into the handset. Select the one that best suits your mood of the day and have it displayed as a background on your screen.

Great for gaming

Let your phone be your stress relief. Sit back, select a game and set a new high score!

Keep in touch by SMS texting

The SMS is a simple way to exchange information over the telephone line. You first type your text off-line and when you are ready, you send it to as many people as you like.

VIP function

Identify who's calling by the ringtone! The VIP icons and melodies indicate to which group in the phonebook the caller belongs. Phonebook entries can be divided in different VIP groups for which you can allocate a specific ringtone.

Backlit display & keypad

Backlit display & keypad ensures easy viewing and operation in low light conditions

Virtually interference free

Thanks to an advanced digital technology, calls are undisturbed by interferences from other devices.

Speakerphone - Talk handsfree

Handsfree mode uses a built-in loud speaker to amplify the voice of the caller, allowing you to speak and listen during a call without holding the phone to your ear. This is especially useful if you want to share the call with others or take notes during a call.

Polyphonic ringtones

A polyphonic ringtone means that the phone can play many tones simultaneously, so that an accurate musical performance is possible, and when played through the phone's speaker these polyphonic ringtones sound like real music.



Issue date 2007-12-07

Version: 2.0

12 NC: 9961 400 05745
EAN: 87 10895 94919 4

© 2007 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com